

3516 GEN SET ENGINE  
 Engine Serial Prefix - 25Z (Build Date - 01/1998, Test Date - 01/1998)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (25Z)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
		I	LA0530	13	001	3516 1360 EKW 60 HZ PGS-PRIME
	<a href="#">NPR</a>	IRY	<a href="#">107-7346</a>	05	001	ENGINE AR
		I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
	<a href="#">NPR</a>	IY	<a href="#">4P-0558</a>	00	001	AIR CLEANER GP
	<a href="#">NPR</a>	I	4P-4574	00	001	GENERATOR AR
	<a href="#">NPR</a>	IY	<a href="#">5N-2438</a>	05	001	LINES GP-FLEXIBLE FUEL
		I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	IY	<a href="#">6I-0134</a>	05	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">7C-0527</a>	02	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">7W-5224</a>	00	001	PULLEY GP-FAN DRIVE
	<a href="#">NPR</a>	IY	<a href="#">7W-5639</a>	02	001	FAN GP-BLOWER
	<a href="#">NPR</a>	IY	<a href="#">7W-6669</a>	01	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	I	7W-8708	00	001	INSTALLATION AR-GENERATOR
	<a href="#">NPR</a>	IY	<a href="#">8N-9639</a>	04	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	IY	<a href="#">115-7182</a>	01	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	IY	<a href="#">7W-7214</a>	04	001	GUARD GP-BELT
	<a href="#">NPR</a>	I	115-3056	02	001	CONNECTION GP-TERMINAL STRIP
	<a href="#">NPR</a>	IY	<a href="#">141-1809</a>	01	001	BOX GP-GENERATOR CONNECTION
	<a href="#">NPR</a>	IY	<a href="#">141-4987</a>	01	001	COVER GP-GENERATOR
	<a href="#">NPR</a>	IY	<a href="#">144-9059</a>	00	001	TRANSFORMER GP-CURRENT
	<a href="#">NPR</a>	IY	<a href="#">131-5454</a>	01	001	CONTROL AS-GOVERNOR
	<a href="#">NPR</a>	IY	<a href="#">8N-6435</a>	02	001	FILTER GP-PRIMARY FUEL
	<a href="#">NPR</a>	IY	<a href="#">107-0165</a>	01	001	PUMP GP-FUEL PRIMING
		I	PA4393	05	001	JACKET WATER HEATER - DUAL
	<a href="#">NPR</a>	IY	<a href="#">6I-1043</a>	01	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">6I-1044</a>	05	001	MOUNTING GP-JACKET WTR HEATER

**PART NUMBERS**

	<a href="#">NPR</a>	IY	<a href="#">7E-6248</a>	05	001	HEATER GP-JACKET WATER
		I	LA0457	01	001	DIGITAL VOLTAGE REGULATOR
	<a href="#">NPR</a>	I	121-6203	03	001	REGULATOR GP-VOLTAGE
		I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
	<a href="#">NPR</a>	I	145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
		I	LA0003	00	001	PANEL AR-PREMIUM-RH
	<a href="#">NPR</a>	IY	<a href="#">4W-6463</a>	06	001	LINES GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	IY	<a href="#">4W-6887</a>	07	001	PANEL GP-INSTRUMENT
	<a href="#">NPR</a>	IY	<a href="#">7E-3159</a>	00	001	TACHOMETER GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">109-1772</a>	00	001	LINES GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	IY	<a href="#">109-3862</a>	01	001	LINES GP-INSTRUMENT PANEL
		I	LA0389	10	001	SWITCHGEAR CONVERSION
	<a href="#">NPR</a>	IY	<a href="#">2W-8947</a>	02	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	IY	<a href="#">2W-9593</a>	05	001	METER GP-SERVICE
	<a href="#">NPR</a>	IY	<a href="#">4W-4755</a>	02	001	SWITCH GP-MAGNETIC
	<a href="#">NPR</a>	IY	<a href="#">7W-9265</a>	01	001	LINES GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	IY	<a href="#">9Y-7876</a>	01	001	DRAIN GP-ENGINE OIL
		I	PA5313	03	001	LUBRICATING OIL
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
	<a href="#">NPR</a>	IY	<a href="#">3E-0264</a>	02	001	SWITCH GP-TEMPERATURE
		I	LA0468	00	001	CIRCUIT BKR W/ST 3200 A
	<a href="#">NPR</a>	I	105-7929	02	001	CIRCUIT BREAKER GP
	<a href="#">NPR</a>	I	122-0317	02	001	PANEL AS-BOX
	<a href="#">NPR</a>	I	122-0319	02	001	MOUNTING GP-CIRCUIT BREAKER
	<a href="#">NPR</a>	I	122-0320	01	001	WIRING GP-GENERATOR
	<a href="#">NPR</a>	I	122-0332	02	001	CABLE GP
	<a href="#">NPR</a>	I	105-7932	01	001	SWITCH AS-AUXILIARY
		I	LA1544	01	001	RADIATOR 46/CV
	<a href="#">NPR</a>	IY	<a href="#">7W-3953</a>	08	001	DRIVE GP-FAN
	<a href="#">NPR</a>	IY	<a href="#">9Y-6676</a>	03	001	RADIATOR GP
	<a href="#">NPR</a>	IY	<a href="#">7W-5224</a>	00	001	PULLEY GP-FAN DRIVE
	<a href="#">NPR</a>	IY	<a href="#">7E-9267</a>	00	001	SWITCH GP-COOLANT LEVEL
	<a href="#">NPR</a>	IY	<a href="#">7E-6681</a>	03	001	COOLER GP-FUEL
		I	PA1613	04	001	ALARM CONTACTORS OP/WT
	<a href="#">NPR</a>	IY	<a href="#">7W-6959</a>	02	001	CONTACTOR GP
	<a href="#">NPR</a>	IY	<a href="#">9Y-0914</a>	05	001	SWITCH GP-TEMPERATURE

		I	LA0183	04	001	FUMES DISPOSAL
	<a href="#">NPR</a>	IY	<a href="#">4W-0472</a>	04	001	FUMES DISPOSAL GP
	<a href="#">NPR</a>	IY	<a href="#">9Y-5563</a>	00	001	FUMES DISPOSAL GP
		I	PA1037	11	001	REMOVAL AR. - RADIATOR
		I	0P-1578		001	PRIME PLUS 10% RATING-3500
		I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
		I	0P-7607		001	SHRINK WRAP PROTECTION - 3516
		I	0P-9799		001	STD G.S. TVA REPORT
		I	0P-1853		001	CHARGE FOR STD. ENGINE/GEN-
		I	0P-8910		001	POST SALE SPAR
		I	0P-9397		001	CIRCUIT BREAKER DISCLAIMER
		I	PP2435	01	001	1967 BHP 1410 GEN KW WOF 60 HZ
		I	2T-6230	00	001	1467 KW @ 1800 RPM (1967 BHP)
						<b>SHIPPED LOOSE</b>
	<a href="#">NPR</a>	S	0S-1588		004	BOLT
	<a href="#">NPR</a>	S	1L-3769		001	RING-RETAINING
	<a href="#">NPR</a>	S	1W-0531		001	BASE-PRIMARY FUEL FILTER
	<a href="#">NPR</a>	S	2H-3429		001	RING-RETAINING
	<a href="#">NPR</a>	S	2J-0157		001	SEAL-O-RING
	<a href="#">NPR</a>	S	2N-8928		004	CLIP
	<a href="#">NPR</a>	S	3E-3361		001	PLUG AS-CONNECTOR
	<a href="#">NPR</a>	S	3E-3362		001	WEDGE-PLUG LOCK
	<a href="#">NPR</a>	SY	<a href="#">3N-6504</a>		001	HOSE AS
	<a href="#">NPR</a>	S	5F-5990		002	CLIP
	<a href="#">NPR</a>	S	5M-2894		008	WASHER-HARD
	<a href="#">NPR</a>	S	5P-0597		001	CLAMP-HOSE
	<a href="#">NPR</a>	S	5P-1472		290	HOSE
	<a href="#">NPR</a>	S	6V-6866		002	PLUG
		S	7C-1880		001	DIAGRAM - WIRING
	<a href="#">NPR</a>	S	7H-9678		001	RETAINER-ELEMENT
	<a href="#">NPR</a>	S	7N-1628		001	NUT
	<a href="#">NPR</a>	S	7S-9323		001	SPRING
	<a href="#">NPR</a>	S	8H-2778		001	SEAL-RING
	<a href="#">NPR</a>	S	8H-7202		001	CASE AS-FUEL FILTER
	<a href="#">NPR</a>	S	8N-1186		001	HOSE AS
	<a href="#">NPR</a>	S	8N-1663		001	BOOT

	<a href="#">NPR</a>	S	8T-8730	002	SOCKET-CONNECTOR
	<a href="#">NPR</a>	S	9M-2342	001	FILTER ELEMENT-FUEL
	<a href="#">NPR</a>	S	9S-8752	004	NUT-FULL
	<a href="#">NPR</a>	SY	<a href="#">131-5454</a>	001	CONTROL AS-GOVERNOR
		S	LERX5100	001	SOFT
		S	SEBP1573	001	PTSBK
		S	SEBP2414	001	PTSBK
		S	SEBU6042	001	SUPP (GEN ONLY) 1632-05 (A)
		S	SEBU6251	001	LUBE
		S	SEBU6701	001	OMM
		S	SEBU6918	001	OMM(GEN ONLY) FL CC06E(A)
		S	SEBU6984	001	SUPP
		S	SELF5260	001	WARRANTY 140013C2(A)
		S	SELS0086	001	S.I.
		S	SELS0115	001	S.I.
		S	SELS0117	001	S.I.
		S	SENR4794	001	DIAGRAM 1634-04 (A)
		S	ESO	001	(PRNT ESO COPY)
		S	PML	001	*REQUIRED DECALS

Key:

I Installed

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE

S Shipped Loose