

3412 GEN SET ENGINE

Engine Serial Prefix - 2WJ (Build Date - 11/1999, Test Date - 11/1999, Ship Date - 11/1999)

▼ ENGINE - ENTIRE GROUP (2WJ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00725	F	001	725 EKW W/FAN
		I	412DE11	F	001	3412 725 EKW 60 HZ PGS-PRIME
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	EMCDP01	F	001	DUST-PROOF CONTROL PANEL
		I	RADF002	F	001	RADIATOR F 0.525 DRIVE
		I	BAT2401	F	001	24 VOLT BATTERY SET - DRY 01
		I	JWH0005	F	001	JACKET WATER HEATER
		I	ACLDE05	F	001	AIR CLEANER - DUAL ELEMENT
		I	ACLRM05	F	001	REG. DUTY AIR CLEANER REMOVAL
		I	BTC1006	F	001	BATTERY CHARGER 10 AMP
		I	ALT2424	F	001	CHARGING ALTERNATOR 24V 45 AMP
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	PRIMEPA	F	001	PRIME POWER
		I	ELECGOV	F	001	ELECTRONIC GOVERNOR
		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
						PART NUMBERS
		I	PP2203	00	001	1071 BHP 759 GEN KW WOF 60 HZ
	NPR	ILY	7E-9054	03	001	GUARD GP-BELT
		I	9E-4122	00	001	SR4 GENERATOR AR - POWER
	NPR	ILY	106-3581	01	001	GENERATOR AR
		I	0P-8707		001	QUOTE NO.
		I	PA5358	03	001	3412 725 EKW 60 HZ PGS-PRIME
	NPR	IY	7E-1091	12	001	ENGINE AR
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	NPR	IY	3N-6668	05	001	LINES GP-FLEXIBLE FUEL
	NPR	IY	4N-1061	14	001	STARTING MOTOR GP-ELECTRIC
	NPR	IY	4P-7610	02	001	SENSOR GP-SPEED
		I	5N-7562	00	001	CHART
		I	5P-2506	00	001	LITERATURE GP
	NPR	IY	6I-2026	04	001	CONNECTION GP-ELECTRICAL
	NPR	IY	6N-8878	02	001	GAUGE GP-FUEL PRESSURE
	NPR	IY	9Y-6397	05	001	RAIL GP-ENGINE SUPPORT
	NPR	IY	102-9942	00	001	MOUNTING GP-CONTACTOR

	NPR	IY	103-1966	05	001	WIRING GP-ENGINE
	NPR	IY	103-6101	04	001	CONTROL GP-ENGINE MONITORING
	NPR	IY	104-4704	03	001	MOUNTING GP-CONTROL PANEL
	NPR	IY	108-1467	01	001	COUPLING GP-GENERATOR
		I	5N-9677		001	NOTE-PANEL CHART 1369048
		I	121-4713	00	001	INSTRUCTIONS
	NPR	IY	121-4712	01	001	PANEL GP-ELECTRONIC
	NPR	IY	121-4705	01	001	SEAL GP-ENCLOSURE
		I	PA5612	02	001	RADIATOR F 0.525 DRIVE
	NPR	IY	6N-5724	05	001	RADIATOR GP
	NPR	IY	6N-5772	03	001	LINES GP-WATER
	NPR	IY	7N-2849	02	001	DRIVE GP-FAN
	NPR	IY	7L-7872	08	001	BATTERY GP
		I	PA5399	01	001	JACKET WATER HEATER
	NPR	IY	7E-4244	01	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	7E-6248	06	001	HEATER GP-JACKET WATER
	NPR	IY	142-9999	01	001	AIR CLEANER GP
		I	PA6015	01	001	REG. DUTY AIR CLEANER REMOVAL
	NPR	IY	7C-3874	02	001	BATTERY CHARGER
		I	PA5346	01	001	CHARGING ALTERNATOR 24V 45 AMP
	NPR	IY	4P-4061	01	001	MOUNTING GP-ALTERNATOR
	NPR	IRY	5N-5692	11	001	ALTERNATOR GP-CHARGING
	NPR	IY	103-7286	01	001	MOUNTING GP-CIRCUIT BREAKER
		I	PP2203	00	001	1071 BHP 759 GEN KW WOF 60 HZ
		I	2T-5778	00	001	800 KW @ 1800 RPM (1071 BHP)
						SHIPPED LOOSE
	NPR	S	0S-1566		008	BOLT
	NPR	S	0S-1585		008	BOLT
	NPR	S	0S-1594		002	BOLT
	NPR	S	0T-0065		001	BOLT
	NPR	S	1F-7958		008	NUT-FULL
	NPR	SY	1N-9420		001	RADIATOR & FAN AS
	NPR	S	1W-1325		001	BRACKET AS-AIR CLEANER
	NPR	S	2F-4967		002	SPACER
	NPR	S	2H-3755		018	BOLT
	NPR	S	2L-3331		002	CONNECTOR-PIPE
	NPR	S	2V-7397		001	CABLE AS
	NPR	S	3B-1915		001	BOLT
	NPR	S	3B-6552		002	ELBOW-PIPE
	NPR	S	3N-2451		002	JOINT AS-TUBE

	NPR	S	3N-6667		002	HOSE AS
	NPR	S	3N-8591		002	FILM-INFORMATION
	NPR	S	4B-4043		004	BOLT
	NPR	S	4D-3704		016	WASHER-HARD
	NPR	S	4K-0367		004	NUT-FULL
	NPR	S	4P-1981	02	001	BRACKET AS
	NPR	SY	4W-5828		002	CAP AS-AIR CLEANER
	NPR	S	5L-3233		002	FITTING-CONNECTOR
	NPR	S	5L-8471		001	HOSE
	NPR	S	5M-2894		006	WASHER-HARD
	NPR	S	5P-0598		004	CLAMP-HOSE
	NPR	S	5P-1717		002	CLAMP-HOSE
	NPR	S	5P-3860		004	CLAMP-HOSE
	NPR	S	5P-8245		016	WASHER-HARD
	NPR	S	5S-7379	02	005	BOLT
	NPR	S	6L-4854		002	HOSE
	NPR	S	6L-9850		001	CAP-PRESSURE
	NPR	S	6N-5752		001	PULLEY-FAN DRIVE
	NPR	S	6N-5755		001	PULLEY-IDLER
	NPR	S	6V-4611		001	FILM-WARNING
	NPR	S	6V-8189		008	NUT
	NPR	SY	7C-3874		001	BATTERY CHARGER
	NPR	S	7E-9797	02	001	COVER AS-ALTERNATOR
	NPR	S	7E-9804	02	001	PLATE
	NPR	S	7E-9805	02	001	PLATE AS
	NPR	S	7E-9806	02	001	BRACKET AS
	NPR	S	7L-4196		001	JOINT AS-TUBE
	NPR	S	7N-2559		001	TUBE AS
	NPR	S	7N-2560		001	TUBE AS
	NPR	S	7N-3115		001	TUBE
	NPR	S	7N-3116		001	GUARD AS-BELT
	NPR	S	7N-3122		001	V-BELT SET
	NPR	S	7N-3559		001	GUARD AS
	NPR	S	7N-3564		001	GUARD AS
	NPR	S	7W-9991	02	001	SEAL
	NPR	S	8B-8679		002	SPACER
	NPR	S	8L-8413		002	STRAP-CABLE
	NPR	S	8N-2694		002	INDICATOR-AIR FILTER CHANGE
	NPR	S	8T-4224	02	022	WASHER-HARD
	NPR	S	8T-4896	02	027	WASHER-HARD

	NPR	S	8T-6763		001	PLUG-PIPE
	NPR	S	8T-9043	02	014	BOLT
	NPR	S	9B-7237		002	BOLT
	NPR	S	9G-0003		002	COVER AS-TERMINAL
	NPR	S	9G-0004		002	COVER AS-TERMINAL
	NPR	S	9M-1974		018	WASHER-HARD
	NPR	S	9S-8752		002	NUT-FULL
	NPR	SY	9X-9730		002	BATTERY GP
		S	SEBP2268		001	PT BK 1690 4-7(A)
		S	SEBP2534		001	PT BK(EMCP 11) 140015B1(A)
		S	SEBP2678		001	PT BK(EMCP 2) 1688 6-9(A)
		S	SEBU6042		001	SUPP (GEN ONLY) 1632-05 (A)
		S	SEBU6251		001	LUBE
		S	SEBU6767		001	OMM 1690 3-1(A)
		S	SEBU6918		002	OMM(GEN ONLY) FL CC06E(A)
		S	SEBU6981		001	SUPP
		S	SEBU6984		001	SUPP
		S	SEHS9213		001	S.I. 1632-02 (A)
		S	SEHS9866		001	S.I. 16881-11(A)
		S	SEHS9970		001	S.I. FORM 1632-01 (A)
		S	SELF5260		001	WARRANTY 140013C2(A)
		S	SENR4794		001	DIAGRAM 1634-04 (A)
		S	SENR4797		001	DIAGRAM 140012D3(A)
	NPR	S	003-2143		001	ELBOW
	NPR	S	138-3230		001	BRACE
	NPR	S	138-3231		001	BRACE
	NPR	S	138-4173		001	SUPPORT AS-AIR CLEANER
	NPR	S	138-4174		001	SUPPORT AS-AIR CLEANER
	NPR	S	138-4551		001	HOSE
	NPR	S	145-6673		001	HOSE
	NPR	SY	159-8566		001	AIR CLEANER GP
	NPR	SY	159-8567		001	AIR CLEANER GP