

G3520C GENERATOR SET

Engine Serial Prefix - GZN (Build Date - 08/2008, Test Date - 09/2008)

▼ ENGINE - ENTIRE GROUP (GZN)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	520GE27	F	001	G3520C 1500RPM CHP JW-99C
		I	OGNPM9E	F	001	GEN 828 FRAME PM 2 BRG 9E
		I	EMCSM01	F	001	SYNCHRONIZING MODULE
		I	RPA0224	F	001	828 FRAME GENERATOR REMOVAL
		I	CAACBX1	F	001	CABLE ACCESS BOX
		I	JWH0019	F	001	JACKET WATER HEATER-400V 50HZ
		S	ACLDE02	F	001	AIR CLEANER - DUAL ELEMENT
		S	BAT2417	F	001	24 VOLT BATT SET-DRY-2600 CCA
		I	BATRM01	F	001	STANDARD BATTERY REMOVAL
		S	EXCFL06	F	001	FLANGE, 305 MM (12 IN)
		I	ELEPAC3	F	001	ELECTRIC PRELUBE PUMP-AC 3
		I	EXRVAL7	F	001	EXPLOSION RELIEF VALVE
		S	LSMOD03	F	001	GOVERNOR - LOAD SHARE MODULE
		I	BARGP01	F	001	ENGINE BARRING GROUP
		I	50H-3300	F	001	50HZ 3300 VOLTS
		I	CONTINU	F	001	CONTINUOUS APPLICATION
		I	EECDOI1	F	001	EEC DECLARATION OF INCORP.
		I	MSEPGGN	F	001	GENERAL EPG
		I	DPX0001	F	001	DOMESTIC PACK-EXPORT CONTAINER
		I	TSP0002	F	001	SPECIAL TEST CHARGE
		I	MSCEC70	F	001	ENERGY UTILITIES
		I	MWCODEH	F	001	COGENERATION
		I	ACTEMP	F	001	94C/54C TWO STAGE
		I	EMISS15	F	001	250 MG/NM3 NOX @ 5% 02
		I	JWTEMP2	F	001	99C JACKET WATER OUTLET
		I	KVA2500	F	001	2500 KVA W/O FAN
		I	PARGRID	F	001	PARALLEL-TO-GRID MODE
		I	0V-2329	F	001	PRODUCTION CORRECTION
	<u>NPR</u>	ILY	<u>128-3623</u>	F	001	MODULE GP-SYNCHRONIZING LIGHTS
						PART NUMBERS
		I	LA4304	03	001	G3520C 1500RPM CHP PKG, 99C LF
	<u>NPR</u>	IY	<u>260-3693</u>	01	001	ENGINE AR
	<u>NPR</u>	IY	<u>2W-8772</u>	04	001	FLYWHEEL GP

	NPR	IY	190-8490	00	001	COVER GP-REGULATOR HOUSING
	NPR	IY	190-8839	02	001	FASTENER GP-OIL PAN
	NPR	IY	190-8842	00	001	PLUG GP-OIL PAN
	NPR	IY	190-8843	00	001	DRAIN GP-ENGINE OIL
	NPR	IY	191-6658	00	001	STARTING MOTOR GP-ELECTRIC
	NPR	IY	191-8721	03	001	COVER GP-GEAR INSPECTION
	NPR	IY	200-6405	09	001	LINES GP-ENGINE OIL
	NPR	IY	200-6406	04	001	MANIFOLD GP-WATER
	NPR	IY	200-6420	07	001	FILTER GP-ENGINE OIL
	NPR	IY	200-6433	05	001	LINES GP-WATER
	NPR	IY	200-6438	02	001	AFTERCOOLER GP-WATER
	NPR	IY	200-6527	06	001	TURBOCHARGER GP
	NPR	IY	200-6538	06	001	LINES GP-AIR
	NPR	IY	200-6550	12	001	MANIFOLD GP-EXHAUST
	NPR	IY	201-1483	05	001	MOUNTING GP-CONTROL
	NPR	IY	203-9448	00	001	GUARD GP-DAMPER
	NPR	IY	204-0854	00	001	CAMSHAFT GP
	NPR	IY	204-5702	03	001	LINES GP-TURBOCHARGER WATER
	NPR	IY	204-6483	04	001	COVER GP-ENGINE
	NPR	IY	204-6719	02	001	LINES GP-FUEL
	NPR	IY	204-6722	04	001	ELBOW GP-AIR INLET
	NPR	IY	205-9452	08	001	CONTROL & MTG GP-ENGINE ELEK
	NPR	IY	207-2451	06	001	SENSOR GP-ENGINE
	NPR	IY	207-2453	04	001	WIRING GP-SENSOR
	NPR	IY	208-2900	03	001	COVER GP-ACCESSORY DRIVE
	NPR	IY	209-0819	04	001	CONNECTION GP-WATER
	NPR	IY	211-1074	02	001	BREATHER GP
	NPR	IY	216-2684	02	001	SHIELD GP-EXHAUST
	NPR	IY	220-2966	07	001	LINES GP-AIR
	NPR	IY	221-8452	00	001	PISTON GP
	NPR	IY	222-7872	09	001	IGNITION GP-GAS ENGINE
	NPR	IY	223-8471	08	001	WIRING GP-ENGINE
	NPR	IY	227-3184	00	001	SHIELD GP-MANIFOLD
	NPR	IY	227-3185	01	001	SHIELD GP-MANIFOLD
	NPR	IY	232-0422	01	001	HOUSING & REGULATOR GP
	NPR	IY	220-0468	01	001	COVER GP-ENGINE LIFTING EYE
	NPR	IY	223-9772	00	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	NPR	IY	223-4916	01	001	COVER GP-ACCESSORY DRIVE
	NPR	IY	240-7096	00	001	PLUG GP-ENGINE
	NPR	IY	216-3700	03	001	WIRING GP-SHUTOFF

	NPR	IY	241-5937	01	001	LINES GP-WATER
	NPR	IY	234-1840	03	001	ADAPTER GP-EXHAUST DIFFUSER
	NPR	IY	278-1348	01	001	GEAR GP-FRONT
	NPR	IY	205-7860	09	001	FILM GP
	NPR	IY	319-8494	01	001	DAMPER GP
		I	LE6567	12	001	G3520 50 HZ GEN SET W/O WATER
		I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
		I	3L-0462		001	TEST- GAS GENSSET
		I	3L-0467		001	TWO BEARING GEN ALIGNMENT-3500
	NPR	SY	3N-7056	00	002	SUPPORT GP-BATTERY
	NPR	SY	7W-0825	01	002	CABLE GP-BATTERY
	NPR	IY	121-6202	10	001	REGULATOR GP-VOLTAGE
	NPR	IY	141-1809	03	001	BOX GP-GENERATOR CONNECTION
		I	198-1905	00	001	PAINT
	NPR	IY	208-5885	03	001	RAIL GP-ENGINE SUPPORT
	NPR	SY	220-3435	00	001	MOUNTING GP-VIBRATION ISOLATOR
	NPR	IY	232-4878	01	001	SWITCH GP-DISCONNECT
	NPR	IY	242-7961	02	001	WIRING GP-GENERATOR
	NPR	IY	3N-8594	06	003	COVER GP-ENGINE LIFTING EYE
	NPR	IY	121-9640	05	001	CONNECTION GP-ELECTRICAL
	NPR	SY	9Y-8220	02	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	I	283-0781	00	541	OIL
	NPR	IY	247-0305	05	001	INSTALLATION AR-GENERATOR
		I	LA5003	01	001	828 FRAME 3300V GENERATOR
	NPR	IY	144-2006	02	001	GENERATOR AR
	NPR	IY	144-9066	02	001	TRANSFORMER GP-CURRENT
	NPR	IY	178-7193	01	001	TRANSFORMER GP-POTENTIAL
		I	LE0318	01	001	SYNCHRONIZING MODULE
		I	LE6537	06	001	828 FRAME GEN REMOVAL FOR THE
		I	LE0609	01	001	CABLE ACCESS BOX
	NPR	IY	122-1194	01	001	BOX & MOUNTING GP
		I	LE6823	04	001	G3520C JW HEATER W/PUMP F/U/W
	NPR	IY	231-5072	05	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	231-6269	02	001	CONNECTION GP-WATER
	NPR	IY	247-3781	04	001	COVER GP-CYLINDER BLOCK
	NPR	IY	291-5106	00	001	HEATER GP-JACKET WATER
		I	LA3771	03	001	INTAKE AIR FILTERS
	NPR	SY	163-8762	00	001	AIR CLEANER GP
		I	LE0176	06	001	OVERSIZE BATTERY - 2600CCA
	NPR	SY	7L-7872	09	002	BATTERY GP

	I	LE0952	04	001	REMOVAL AR, BATTERIES, CABLES,
	I	LE0140	01	001	305MM (12 INCH) FLANGE GP
	NPR	SY 2W-7871	03	001	FLANGE GP-EXHAUST
	I	LA3773	00	001	G3520C/E 1500 RPM PRELUBE SYST
	NPR	IY 210-2465	06	001	PUMP GP-PRELUBRICATION
	I	LA3775	00	001	G3520C EXPLOSION RELIEF VALVES
	I	LA3769	00	001	FILTER GP - FUMES (PCV)
	NPR	SY 200-3057	00	001	FUMES DISPOSAL GP
	NPR	SY 202-4869	00	001	CONTROL AS-GOVERNOR
	I	LA4224	00	001	BARRING GP-RIGHT HAND
	NPR	IY 257-2143	01	001	BARRING & MOUNTING GP
	I	5N-9591		001	VOLTAGE INDICATOR 3300V, 50HZ
	I	9Y-8164		001	CONTINUOUS POWER APPLICATION
	I	LA1311	06	001	EEC DECLARATION OF INCORP.
	I	5N-9622		001	NOTE-EEC (ENGINE)
	I	0P-7824		001	DOMESTIC PACK-EXPORT CONTAINER
	I	0V-1065		001	END USE: GENERAL EPG
	I	0P-1513		001	SPECIAL TEST CHARGE
	I	LL0587	00	001	2776 BHP 2000 EKW WOF 50 HZ
	I	0K-6513		001	2070 BKW (2776 BHP) @ 1500 RPM
	S	101-9242	00	001	LITERATURE GP
	S	ESO		001	SHIPPED LOOSE
	S	PML		001	(PRNT ESO COPY)
	S	PML		001	*REQUIRED DECALS
	NPR	S 0S-1571		012	BOLT
	NPR	S 0S-1594		002	BOLT
	NPR	S 1B-5355		012	NUT-FULL
	NPR	S 1B-5357		012	NUT-FULL
	NPR	S 1S-0178		001	CONNECTOR-HOSE
	NPR	S 1V-7753		001	SPACER
	NPR	S 2V-7397		002	CABLE AS
	NPR	SY 2W-7871		001	FLANGE GP-EXHAUST
	NPR	S 2W-7872		001	FLANGE-EXHAUST
	NPR	S 2W-7873		001	GASKET-EXHAUST
	NPR	S 3B-6552		001	ELBOW-PIPE
	NPR	S 3B-7725		002	CAP-PIPE
	NPR	S 3K-1715		002	CABLE AS
	NPR	S 3N-7054		002	SUPPORT AS-BATTERY

	NPR	S	3N-7055	002	BOARD
	NPR	SY	3N-7056	001	SUPPORT GP-BATTERY
	NPR	S	3V-6785	002	CABLE AS
	NPR	S	4W-3637	001	HOSE
	NPR	S	5K-3294	001	CLIP
	NPR	S	5L-3233	001	FITTING-CONNECTOR
	NPR	S	5L-4398	012	BOLT
	NPR	S	5M-2894	002	WASHER-HARD
	NPR	S	5P-1505	750	HOSE
	NPR	S	5P-4961	002	CLAMP-HOSE
	NPR	S	5P-8245	024	WASHER-HARD
		SY	6L-4502	001	CHART-PLATE & FILM
	NPR	SY	7L-7872	001	BATTERY GP
	NPR	S	7N-5274	002	COVER AS-TERMINAL
	NPR	SY	7W-0825	001	CABLE GP-BATTERY
	NPR	S	8L-8413	004	STRAP-CABLE
	NPR	S	8N-0869	002	COVER-TERMINAL
	NPR	S	8N-1725	002	COVER AS-TERMINAL
	NPR	S	8T-4994	010	WASHER-HARD
	NPR	S	9G-0003	004	COVER AS-TERMINAL
	NPR	S	9G-0004	004	COVER AS-TERMINAL
	NPR	S	9G-8909	002	COVER-TERMINAL
	NPR	S	9L-1480	001	GASKET
	NPR	S	9L-9132	024	WASHER
	NPR	S	9S-1366	001	BOLT
	NPR	SY	9X-9730	004	BATTERY GP
	NPR	SY	9Y-8220	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	S	9Y-8869	001	INDICATOR
	NPR	S	116-8535	008	CLAMP
	NPR	SY	141-7959	001	AIR CLEANER GP
	NPR	SY	144-2006	001	GENERATOR AR
	NPR	SY	163-8762	001	AIR CLEANER GP
	NPR	SY	171-6719	001	KIT-PARTS
	NPR	S	178-5048	010	ISOLATOR AS
	NPR	SY	191-2304	001	FILTER GP-FUMES DISPOSAL
	NPR	S	199-1011	001	TUBE AS-DRAIN
	NPR	SY	200-3057	001	FUMES DISPOSAL GP
	NPR	SY	202-4869	001	CONTROL AS-GOVERNOR
	NPR	SY	220-3435	001	MOUNTING GP-VIBRATION ISOLATOR
		S	SERP3868	001	PTSCD



S	SLBU6400	001	LUBE
S	SLBU7681	001	OMM