

3508C PETROLEUM ENGINE

Engine Serial Number - LLC (Build Date - 11/2006, Test Date - 11/2006)

▼ ENGINE - ENTIRE GROUP (LLC)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	508DZ22	F	001	3508C LAND ELEC DRILLING ENG
		I	CLINCN1	F	001	INLET CONNECTION
		S	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	GOVPG08	F	001	GOVERNOR CONVERSION
		S	PFF0001	F	001	PRIMARY FUEL FILTER
		S	FUMDIS1	F	001	FUMES DISPOSAL
		I	FLXCP01	F	001	FLEXIBLE COUPLING
		S	COUHUB0	F	001	COUPLING HUB
		I	JWHD002	F	001	JACKET WATER HEATER - DUAL
		I	ALT2412	F	001	CHARGING ALT 24V 60 AMP
		I	BARGP01	F	001	ENGINE BARRING GROUP
		I	1200RPM	F	001	1200 RPM
		I	MSPETEP	F	001	PETROLEUM EPG
		I	SWPENG2	F	001	SHRINK WRAP ENGINE ONLY
		I	MSCP12	F	001	DRILLING
		I	MWCODEE	F	001	PRIME POWER
		I	DM7913A	F	001	915 BHP (682 BKW) W/O FAN .
		I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT
		I	3508C	F	001	3508C DIESEL ENGINE
		I	HP00915	F	001	915 BHP (682 BKW) W/O FAN
		I	LELEENG	F	001	LAND ELECTRIC DRILLING ENGINE
	<u>NPR</u>	IL	151-9228	F	001	GUARD GP-BELT
		IL	5N-9949	F	001	CONVENIENCE NUMB
						PART NUMBERS
		I	LA4511	05	001	3508C LAND ELECTRIC DRILLING E
	<u>NPR</u>	IY	<u>250-7624</u>	14	001	ENGINE AR
	<u>NPR</u>	IY	<u>4W-2767</u>	00	001	CONTACTOR GP
	<u>NPR</u>	SY	<u>5N-2438</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	SY	<u>5N-2457</u>	06	001	FITTING GP-EXHAUST
		S	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	I	5P-2586	04	227	OIL
	<u>NPR</u>	IY	<u>7C-0330</u>	08	001	CONTROL GP-AIR STARTING
	<u>NPR</u>	IY	<u>7C-3371</u>	02	001	STARTING MOTOR GP-AIR
	<u>NPR</u>	IY	<u>7E-6469</u>	09	001	MOUNTING GP-CONTACTOR

	NPR	IY	7N-6782	08	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	SY	7N-6962	06	001	FLANGE GP-EXHAUST
	NPR	SY	7N-6968	05	001	FITTING GP-EXHAUST
	NPR	IY	7W-9269	08	001	LINES GP-AIR STARTING
	NPR	IY	8N-9303	09	001	AIR CLEANER GP
	NPR	IY	8N-9639	04	001	GUARD GP-DAMPER
	NPR	IY	9Y-0845	01	001	RAIL GP-ENGINE SUPPORT
	NPR	IY	107-2855	05	001	MOUNTING GP-INSTRUMENT PANEL
	NPR	IY	112-6597	03	001	SILENCER GP-AIR STARTING
	NPR	IY	115-5164	02	001	BOX & MOUNTING GP
	NPR	IY	115-7841	17	001	FILTER GP-ENGINE OIL
	NPR	IY	125-7089	14	001	BOX GP-INSTRUMENT PANEL
	NPR	IY	134-6315	02	001	WIRING GP-PANEL
	NPR	IY	163-1462	01	001	SENSOR & MTG GP-ELECTRIC
	NPR	IY	210-6112	03	001	DRAIN GP-ENGINE OIL
	NPR	IY	253-7393	02	001	WIRING GP-ENGINE
	NPR	IY	274-5749	01	001	SHUTOFF GP-AIR
	NPR	IY	285-8634	01	001	PUMP GP-FUEL PRIMING
	NPR	IY	285-9159	01	001	FILTER GP-FUEL
	NPR	IY	9Y-9173	04	001	LINES GP-WATER
	NPR	SY	165-6634	03	001	SENSOR GP-COOLANT LEVEL
		I	LA3242	02	001	ENGINE GOVERNOR CONVERSION
	NPR	IY	7W-3355	06	001	SENSOR GP-SPEED
		I	176-1690	00	001	*****TEST-DIRECT F *****
	NPR	IY	180-7385	01	001	CONTROL GP-CONVERTER
	NPR	SY	8N-6435	02	001	FILTER GP-PRIMARY FUEL
		I	LA1061	05	001	FUMES DISPOSAL
	NPR	NY	9Y-5563	03	001	FUMES DISPOSAL GP
	NPR	IY	120-9818	06	001	FUMES DISPOSAL GP
		I	PL1736	17	001	FLEXIBLE COUPLING
	NPR	SY	3N-8647	05	001	FASTENER GP-COUPLING
	NPR	SY	3N-5765	06	001	GUARD GP-COUPLING
		N	3N-9755	00	001	INSTRUCTIONS
	NPR	SY	3N-5764	02	001	GUARD GP-EXTENSION
	NPR	SY	5N-3765	12	001	COUPLING GP-FLEXIBLE
	NPR	SY	4P-9064	00	001	GUARD GP-EXTENSION
	NPR	SY	3N-5596	07	001	HUB-FLEXIBLE COUPLING
		I	PA4389	08	001	JACKET WATER HEATER - DUAL
	NPR	IY	6I-1039	05	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	6I-1040	07	001	MOUNTING GP-JACKET WTR HEATER

	NPR	IY	200-6504	01	002	HEATER GP-JACKET WATER
		I	LA1661	05	001	CHARGING ALTERNATOR 24V 60 AMP
	NPR	IY	7E-2858	06	001	ALTERNATOR GP-CHARGING
	NPR	IY	7E-4836	09	001	MOUNTING GP-ALTERNATOR
	NPR	IY	7W-5780	06	001	GUARD GP-BELT
	NPR	IY	166-4357	00	001	DRIVE GP-ACCESSORY
	NPR	IY	5R-7425	04	001	BARRING GP
		I	0V-1055		001	END USE: PETROLEUM EPG
		I	0P-7577		001	SHRINK WRAP PROTECTION - 3508
		I	LL5673	01	001	AUTHORIZED APPROVAL NUMBER
		I	0K-6375		001	915 BHP 600 GEN KW W/F 60 HZ
		I	0P-1914		001	DOMESTIC PACK FOR EXPORT
		I	0V-2329		001	PRODUCTION CORRECTION
	NPR	IY	151-9229	02	001	GUARD GP-BELT
		IL	5N-9635		001	CONVENIENCE NUM
		I	0V-3462		001	EPA TIER II - NONROAD
						SHIPPED LOOSE
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	NPR	S	0S-1571		008	BOLT
	NPR	S	0S-1588		008	BOLT
	NPR	S	0S-1589		012	BOLT
	NPR	S	0S-1591		008	BOLT
	NPR	S	0S-1594		016	BOLT
	NPR	S	0S-1621		010	BOLT
	NPR	S	1A-8537		012	BOLT
	NPR	S	1L-3769		001	RING-RETAINING
	NPR	S	1V-0623		008	PLATE
	NPR	S	1W-0531		001	BASE-PRIMARY FUEL FILTER
	NPR	S	2H-3429		001	RING-RETAINING
	NPR	S	2J-0157		001	SEAL-O-RING
	NPR	S	2N-3385		016	NUT-CLIP
	NPR	S	2N-8928		004	CLIP
	NPR	S	3B-4506		016	LOCKWASHER
	NPR	S	3B-4508		010	LOCKWASHER
	NPR	S	3L-9689		016	WASHER
	NPR	SY	3N-5596		001	HUB-FLEXIBLE COUPLING
	NPR	S	3N-5708		001	GUARD AS-EXTENSION
	NPR	SY	3N-5764		001	GUARD GP-EXTENSION
	NPR	SY	3N-5765		001	GUARD GP-COUPLING

	NPR	S	3N-6504	001	HOSE AS
	NPR	S	3N-6666	001	COUPLING-DRIVE
	NPR	SY	3N-8647	001	FASTENER GP-COUPLING
		S	3N-9755	001	INSTRUCTIONS
	NPR	S	3V-3308	008	WASHER-HARD
	NPR	S	4B-4280	010	WASHER
	NPR	S	4D-3704	024	WASHER-HARD
	NPR	S	4P-9063	001	GUARD AS-EXTENSION
	NPR	SY	4P-9064	001	GUARD GP-EXTENSION
	NPR	S	4V-8198	008	SPACER
	NPR	S	5F-5990	002	CLIP
	NPR	S	5L-3773	001	GASKET-EXHAUST ELBOW
	NPR	S	5M-2894	012	WASHER-HARD
	NPR	SY	5N-2438	001	LINES GP-FLEXIBLE FUEL
	NPR	SY	5N-2457	001	FITTING GP-EXHAUST
	NPR	S	5N-3272	003	BOOT-RUBBER COUPLING
	NPR	S	5N-3274	001	PLATE
	NPR	S	5N-3284	001	COUPLING-OUTER
	NPR	SY	5N-3765	001	COUPLING GP-FLEXIBLE
	NPR	S	5N-4817	001	GUARD AS-COUPLING
	NPR	S	5N-5561	002	LUBRICANT-SILICONE
	NPR	S	5P-0597	001	CLAMP-HOSE
	NPR	S	5P-1472	290	HOSE
	NPR	S	6F-5985	001	HOSE AS
		SY	6L-4502	001	CHART-PLATE & FILM
	NPR	S	6V-6866	002	PLUG
	NPR	S	6V-8801	004	NUT
	NPR	S	7H-9678	001	RETAINER-ELEMENT
	NPR	S	7N-1628	001	NUT
	NPR	S	7N-5971	001	ADAPTER
	NPR	S	7N-6954	001	FLANGE
	NPR	S	7N-6957	001	GASKET
	NPR	SY	7N-6962	001	FLANGE GP-EXHAUST
	NPR	SY	7N-6968	001	FITTING GP-EXHAUST
	NPR	S	7S-9323	001	SPRING
	NPR	SY	7W-9269	001	LINES GP-AIR STARTING
	NPR	S	8C-6913	008	WASHER-HARD
	NPR	S	8H-2778	001	SEAL-RING
	NPR	S	8H-7202	001	CASE AS-FUEL FILTER
	NPR	S	8N-1186	001	HOSE AS

NPR	S	8N-1663	001	BOOT
NPR	S	8N-2555	002	FILTER-SOOT
NPR	SY	8N-6435	001	FILTER GP-PRIMARY FUEL
NPR	SY	8N-9303	001	AIR CLEANER GP
NPR	S	8T-4896	008	WASHER-HARD
NPR	S	8T-6762	001	PLUG-PIPE
NPR	S	9B-7237	004	BOLT
NPR	S	9H-0846	002	SEAL-O-RING
NPR	S	9M-2342	001	FILTER ELEMENT-FUEL
NPR	S	9S-8752	008	NUT-FULL
NPR	S	9X-8872	008	BOLT-LOCKING
NPR	SY	9Y-5563	001	FUMES DISPOSAL GP
NPR	SY	125-7089	001	BOX GP-INSTRUMENT PANEL
NPR	SY	165-6634	001	SENSOR GP-COOLANT LEVEL
NPR	S	201-8899	008	BOLT-12 POINT HEAD
NPR	S	214-6045	001	BELLOWS AS
	S	REN1243	001	SMGP
	S	REN7678	001	SCHEMATIC
	S	SEBU8101	001	OMM
	S	SERP4366	001	PTSCD