

3406B GEN SET ENGINE

Engine Serial Prefix - 4JK (Build Date - 02/1997, Test Date - 02/1997, Ship Date - 04/1997)

▼ ENGINE - ENTIRE GROUP (4JK)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
		I	PA6172	01	001	<b>PART NUMBERS</b> 3406 DITA/XQ350 RENTAL PKG
	<a href="#">NPR</a>	IY	<a href="#">130-9415</a>	02	001	ENGINE AR
	<a href="#">NPR</a>	IY	<a href="#">1N-3876</a>	01	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">1W-4878</a>	04	001	AIR CLEANER GP
	<a href="#">NPR</a>	IY	<a href="#">1W-7411</a>	02	001	CONTROL GP-GOVERNOR
		I	2T-8141	00	001	SETTING
	<a href="#">NPR</a>	IY	<a href="#">2W-8198</a>	09	001	SHUTOFF GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">4N-1062</a>	10	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">4N-3093</a>	08	001	FAN GP-BLOWER
	<a href="#">NPR</a>	IY	<a href="#">4N-9778</a>	03	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">4P-3359</a>	05	001	COUPLING GP-GENERATOR
		I	4P-6247	01	001	FILM - GENERATOR INFO
	<a href="#">NPR</a>	IY	<a href="#">4P-7610</a>	02	001	SENSOR GP-SPEED
	<a href="#">NPR</a>	IY	<a href="#">4P-9687</a>	01	001	GENERATOR AR
	<a href="#">NPR</a>	IY	<a href="#">4W-1727</a>	00	001	COVER GP-FUEL TRANSFER
	<a href="#">NPR</a>	IY	<a href="#">4W-5828</a>	00	001	CAP AS-AIR CLEANER
		I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
		I	6I-0371	00	001	ENCLOSURE GP
	<a href="#">NPR</a>	IY	<a href="#">6L-2927</a>	07	001	ELBOW GP-EXHAUST
	<a href="#">NPR</a>	IY	<a href="#">6N-8878</a>	02	001	GAUGE GP-FUEL PRESSURE
	<a href="#">NPR</a>	IRY	<a href="#">6N-9294</a>	15	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY	<a href="#">7N-8840</a>	02	001	DRIVE GP-FAN
	<a href="#">NPR</a>	IY	<a href="#">7W-1340</a>	08	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IY	<a href="#">8N-9759</a>	03	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">9G-4231</a>	11	001	BATTERY
	<a href="#">NPR</a>	IY	<a href="#">103-1956</a>	00	001	MOUNTING GP-CONTACTOR
	<a href="#">NPR</a>	IY	<a href="#">103-6101</a>	04	001	CONTROL GP-ENGINE MONITORING

	<a href="#">NPR</a>	IY	<a href="#">103-7284</a>	00	001	MOUNTING GP-CIRCUIT BREAKER
		IY	<a href="#">104-7942</a>	02	001	FASTENER GP-WIRING HARNESS
		IY	<a href="#">104-8615</a>	01	001	TANK & BASE GP-FUEL
	<a href="#">NPR</a>	IY	<a href="#">105-9710</a>	00	001	LINES GP-ENGINE OIL DRAIN
	<a href="#">NPR</a>	IY	<a href="#">106-9931</a>	00	001	LINES GP-COOLANT DRAIN
	<a href="#">NPR</a>	IY	<a href="#">108-0723</a>	03	001	HARNESS GP-WIRING
	<a href="#">NPR</a>	I	109-5264	04	001	PANEL AR-CONTROL
		IY	<a href="#">111-4219</a>	01	001	MOUNTING GP-CONTROL PANEL
	<a href="#">NPR</a>	IY	<a href="#">111-4421</a>	01	001	ACTUATOR AS-GOVERNOR
	<a href="#">NPR</a>	I	111-7534	01	001	MOUNTING GP-ACTUATOR
		I	117-2855	00	001	PLATE & FILM GP
	<a href="#">NPR</a>	IY	<a href="#">131-3533</a>	01	001	PUMP GP-GOV & FUEL INJ
	<a href="#">NPR</a>	IY	<a href="#">131-5544</a>	00	001	RADIATOR GP
	<a href="#">NPR</a>	IY	<a href="#">131-5455</a>	00	001	CONTROL AS-GOVERNOR
		I	PL0615	09	001	JACKET WATER HEATER
	<a href="#">NPR</a>	IY	<a href="#">4N-6540</a>	22	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">7E-6247</a>	02	001	HEATER GP-JACKET WATER

Key:

I Installed

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE