

3412 GEN SET ENGINE

Engine Serial Number - 2WJ (Build Date - 09/1999, Test Date - 09/1999, Ship Date - 10/1999)

▼ ENGINE - ENTIRE GROUP (2WJ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty.</u>	<u>Part Name</u>
						FEATURE CODES
<input type="checkbox"/>		I	KW00800	F	001	800 EKW W/FAN
<input type="checkbox"/>		I	412DE08	F	001	3412 800 EKW 60 HZ PGS-STBY
<input type="checkbox"/>		I	EMCPLUS	F	001	EMCP TWO PLUS
<input type="checkbox"/>		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
<input type="checkbox"/>		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
<input type="checkbox"/>		I	EMCSM01	F	001	SYNCHRONIZING MODULE
<input type="checkbox"/>		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
<input type="checkbox"/>		I	EMCEFR1	F	001	RELAY GP
<input type="checkbox"/>		I	RADD004	F	001	RADIATOR D 0.571 DRIVE
<input type="checkbox"/>		I	CLS0001	F	001	COOLANT LEVEL SENSOR
<input type="checkbox"/>		I	ACT0001	F	001	EXTENDED LIFE COOLANT
<input type="checkbox"/>		I	BAT2401	F	002	24 VOLT BATTERY SET - DRY 01
<input type="checkbox"/>		I	BTRCBL1	F	001	BATTERY CABLES
<input type="checkbox"/>		I	BTR0001	F	001	BATTERY RACK
<input type="checkbox"/>		I	JWH0005	F	001	JACKET WATER HEATER
<input type="checkbox"/>		I	ACLDE05	F	001	AIR CLEANER - DUAL ELEMENT
<input type="checkbox"/>		I	ACLRM02	F	001	LIGHT DUTY AIR CLEANER REMOVAL
<input type="checkbox"/>		I	ALT2422	F	001	CHARGING ALTERNATOR 24V 35 AMP
<input type="checkbox"/>		I	CBK0011	F	001	CIRCUIT BKR W/ST 1200 A
<input type="checkbox"/>		I	CBS3P02	F	001	AUXILIARY SWITCH
<input type="checkbox"/>		I	PFF0004	F	001	PRIMARY FUEL FILTER
<input type="checkbox"/>		I	FUMDIS3	F	001	FUMES DISPOSAL
<input type="checkbox"/>		I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
<input type="checkbox"/>		I	SWP0004	F	001	SHRINK WRAP PROTECTION - 3412
<input type="checkbox"/>		I	60H-0480	F	001	60HZ 480 VOLTS
<input type="checkbox"/>		I	STANDBY	F	001	STANDBY POWER
<input type="checkbox"/>		I	ELECGOV	F	001	ELECTRONIC GOVERNOR
<input type="checkbox"/>		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
						PART NUMBERS
<input type="checkbox"/>		I	PP2201	00	001	1180 BHP 836 GEN KW WOF 60 HZ
<input type="checkbox"/>		I	PA5361	04	001	3412 800 EKW 60 HZ PGS-STBY

	NPR	I	7E-1091	12	001	ENGINE AR
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	NPR	I	3N-6668	05	001	LINES GP-FLEXIBLE FUEL
	NPR	I	4N-1061	14	001	STARTING MOTOR GP-ELECTRIC
	NPR	I	4N-3465	11	001	FAN GP-BLOWER
	NPR	I	4P-7610	02	001	SENSOR GP-SPEED
		I	5N-7562	00	001	CHART
	NPR	I	6I-2026	04	001	CONNECTION GP-ELECTRICAL
	NPR	I	6N-3651	03	001	LINES GP-WATER
	NPR	I	6N-9929	01	001	LINES GP-WATER
	NPR	I	7E-4255	03	001	RADIATOR GP
	NPR	I	7E-9053	01	001	GUARD GP-BELT
	NPR	I	9Y-6397	05	001	RAIL GP-ENGINE SUPPORT
	NPR	I	102-9942	00	001	MOUNTING GP-CONTACTOR
	NPR	I	103-1966	05	001	WIRING GP-ENGINE
	NPR	I	104-4704	03	001	MOUNTING GP-CONTROL PANEL
	NPR	I	106-3581	01	001	GENERATOR AR
	NPR	I	108-1467	01	001	COUPLING GP-GENERATOR
	NPR	I	6N-8878	02	001	GAUGE GP-FUEL PRESSURE
		I	5N-9677		001	NOTE-PANEL CHART 1369048
		I	CA0597	00	001	ELECT. MODULAR CONT. PANEL II+
	NPR	I	141-2858	01	001	CONTROL AR-EMCP ELECTRONIC
	NPR	I	145-5219	01	001	CONTROL GP-ENG RATINGS ELEK
		I	121-4713	00	001	INSTRUCTIONS
	NPR	I	121-4716	01	001	MODULE GP-ALARM
	NPR	I	131-1969	00	001	MODULE GP-SYNCHRONIZING LIGHTS
	NPR	I	121-4712	01	001	PANEL GP-ELECTRONIC
	NPR	I	134-1157	00	001	RELAY GP
		I	PA5607	00	001	RADIATOR D 0.571 DRIVE
	NPR	I	7N-8831	03	001	DRIVE GP-FAN
	NPR	I	111-3794	00	001	SENSOR GP-COOLANT LEVEL
		I	CA0560	01	001	EXTENDED LIFE COOLANT
	NPR	I	119-5148	01	001	COOLANT-EXTENDED LIFE
	NPR	I	7L-7872	08	002	BATTERY GP
	NPR	I	7W-0825	01	001	CABLE GP-BATTERY
	NPR	I	3N-7056	00	001	SUPPORT GP-BATTERY
		I	PA5399	01	001	JACKET WATER HEATER
	NPR	I	7E-4244	01	001	MOUNTING GP-JACKET WTR HEATER
	NPR	I	7E-6248	05	001	HEATER GP-JACKET WATER
	NPR	I	142-9999	01	001	AIR CLEANER GP

	I	PA6012	00	001	LIGHT DUTY AIR CLEANER REMOVAL	
	I	PA5344	01	001	CHARGING ALTERNATOR 24V 35 AMP	
	NPR	I	4P-4063	01	001	MOUNTING GP-ALTERNATOR
	NPR	IR	6T-1395	06	001	ALTERNATOR GP-CHARGING
	NPR	I	7E-9054	03	001	GUARD GP-BELT
	NPR	I	103-7286	01	001	MOUNTING GP-CIRCUIT BREAKER
		I	PA5370	03	001	CIRCUIT BKR W/ST 1200 A
	NPR	I	4P-4968	01	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	I	4P-4969	01	001	BOX GP-EXTENSION TERMINAL
	NPR	I	105-7185	00	001	HARNESS AS-PANEL
	NPR	I	106-9697	00	001	NEUTRAL BUS BAR AS
	NPR	I	108-1055	00	001	FASTENER GP-EXTENSION BOX
	NPR	I	108-1056	00	001	COVER GP-EXTENSION BOX
	NPR	I	108-1057	01	001	CABLE GP-GENERATOR GROUND
	NPR	I	108-1060	00	001	CABLE GP-GENERATOR GROUND
	NPR	I	108-1061	00	001	CIRCUIT BREAKER GP
	NPR	I	105-7931	01	001	SWITCH AS-AUXILIARY
		I	PL1697	06	001	PRIMARY FUEL FILTER
	NPR	I	6N-3212	04	001	MOUNTING GP-PRIMARY FUEL FLTR
	NPR	I	8H-7204	09	001	FILTER GP-FUEL
	NPR	I	7E-4262	04	001	FUMES DISPOSAL GP
	NPR	I	3N-7442	05	001	SWITCH AS-TEMPERATURE
		I	0P-7610		001	SHRINK WRAP PROTECTION - 3412
		I	PP2201	00	001	1180 BHP 836 GEN KW WOF 60 HZ
		I	2T-5777	00	001	880 KW @ 1800 RPM (1180 BHP)
					SHIPPED LOOSE	
	NPR	S	0S-1566		008	BOLT
	NPR	S	0S-1585		008	BOLT
	NPR	S	0S-1594		002	BOLT
	NPR	S	0T-0065		001	BOLT
	NPR	S	1F-7958		008	NUT-FULL
	NPR	S	1W-1325		001	BRACKET AS-AIR CLEANER
	NPR	S	2F-4967		002	SPACER
	NPR	S	2L-3331		002	CONNECTOR-PIPE
	NPR	S	2V-7397		002	CABLE AS
	NPR	S	3B-1915		001	BOLT
	NPR	S	3B-6552		002	ELBOW-PIPE
	NPR	S	3K-1715		001	CABLE AS
	NPR	S	3N-6667		002	HOSE AS
	NPR	S	3N-7054		001	SUPPORT AS-BATTERY

NPR	S	3N-7055	001	BOARD
NPR	S	3V-6785	001	CABLE AS
NPR	S	4B-4043	004	BOLT
NPR	S	4D-3704	016	WASHER-HARD
NPR	S	4K-0367	004	NUT-FULL
NPR	S	4W-5828	002	CAP AS-AIR CLEANER
NPR	S	5L-3233	002	FITTING-CONNECTOR
NPR	S	5M-2894	006	WASHER-HARD
NPR	S	5P-3860	004	CLAMP-HOSE
NPR	S	5P-8245	016	WASHER-HARD
NPR	S	6V-4611	002	FILM-WARNING
NPR	S	7N-5274	001	COVER AS-TERMINAL
NPR	S	8B-8679	002	SPACER
NPR	S	8L-8413	004	STRAP-CABLE
NPR	S	8N-0869	001	COVER-TERMINAL
NPR	S	8N-1725	001	COVER AS-TERMINAL
NPR	S	8N-2694	002	INDICATOR-AIR FILTER CHANGE
NPR	S	8T-4896	022	WASHER-HARD
NPR	S	8T-6763	001	PLUG-PIPE
NPR	S	9B-7237	002	BOLT
NPR	S	9G-0003	004	COVER AS-TERMINAL
NPR	S	9G-0004	004	COVER AS-TERMINAL
NPR	S	9G-8909	001	COVER-TERMINAL
NPR	S	9S-8752	002	NUT-FULL
NPR	S	9X-9730	004	BATTERY GP
	S	SEBP2268	001	PT BK 1690 4-7(A)
	S	SEBP2534	001	PT BK(EMCP 11) 140015B1(A)
	S	SEBP2678	001	PT BK(EMCP 2) 1688 6-9(A)
	S	SEBU6042	001	SUPP (GEN ONLY) 1632-05 (A)
	S	SEBU6251	001	LUBE
	S	SEBU6767	001	OMM 1690 3-1(A)
	S	SEBU6918	002	OMM(GEN ONLY) FL CC06E(A)
	S	SEBU6981	001	SUPP
	S	SEBU6984	001	SUPP
	S	SEHS9213	001	S.I. 1632-02 (A)
	S	SEHS9866	001	S.I. 16881-11(A)
	S	SEHS9970	001	S.I. FORM 1632-01 (A)
	S	SELF5260	001	WARRANTY 140013C2(A)
	S	SENR4794	001	DIAGRAM 1634-04 (A)
NPR	S	003-2143	001	ELBOW

<input type="checkbox"/>	NPR	S	111-5040	001	AIR CLEANER GP
<input type="checkbox"/>	NPR	S	111-5041	001	AIR CLEANER GP
<input type="checkbox"/>	NPR	S	138-3230	001	BRACE
<input type="checkbox"/>	NPR	S	138-3231	001	BRACE
<input type="checkbox"/>	NPR	S	138-4173	001	SUPPORT AS-AIR CLEANER
<input type="checkbox"/>	NPR	S	138-4174	001	SUPPORT AS-AIR CLEANER
<input type="checkbox"/>	NPR	S	138-4551	001	HOSE
<input type="checkbox"/>	NPR	S	145-6673	001	HOSE