

3412 GEN SET ENGINE

Engine Serial Prefix - 81Z (Build Date - 06/1997, Test Date - 06/1997, Ship Date - 07/1997)

▼ ENGINE - ENTIRE GROUP (81Z)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
		I	PA5006	06	001	<b>PART NUMBERS</b> 3412 500 EKW 60 HZ PGS-STBY
	<a href="#">NPR</a>	IY	<a href="#">1W-9602</a>	08	001	ENGINE AR
	<a href="#">NPR</a>	IY	<a href="#">3N-6668</a>	05	001	LINES GP-FLEXIBLE FUEL
	<a href="#">NPR</a>	IY	<a href="#">4N-1061</a>	14	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">4P-7610</a>	02	001	SENSOR GP-SPEED
	<a href="#">NPR</a>	IY	<a href="#">5N-2286</a>	06	001	BASE GP-ENGINE & GENERATOR
	<a href="#">NPR</a>	IY	<a href="#">5N-6132</a>	07	001	LINES GP-COOLANT DRAIN
	<a href="#">NPR</a>	IY	<a href="#">5N-7378</a>	03	001	LINES GP-ENGINE OIL DRAIN
		I	5N-7562	00	001	CHART
	<a href="#">NPR</a>	IY	<a href="#">5N-8293</a>	05	001	SHUTOFF GP-ELECTRICAL
		I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
	<a href="#">NPR</a>	IY	<a href="#">6N-8878</a>	02	001	GAUGE GP-FUEL PRESSURE
	<a href="#">NPR</a>	IY	<a href="#">7C-4366</a>	00	001	MOUNTING GP-CONTACTOR
	<a href="#">NPR</a>	IY	<a href="#">7N-6351</a>	03	001	ELBOW GP-EXHAUST
	<a href="#">NPR</a>	IY	<a href="#">102-9942</a>	00	001	MOUNTING GP-CONTACTOR
	<a href="#">NPR</a>	IY	<a href="#">103-1965</a>	00	001	WIRING GP-PANEL
	<a href="#">NPR</a>	IY	<a href="#">103-6101</a>	04	001	CONTROL GP-ENGINE MONITORING
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	<a href="#">NPR</a>	IY	<a href="#">7E-9052</a>	01	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">104-4704</a>	03	001	MOUNTING GP-CONTROL PANEL
	<a href="#">NPR</a>	IY	<a href="#">7N-4686</a>	01	001	COVER GP-SERVICE METER
		I	5N-7601		001	AUTHORIZED APPROVAL NUMBER
	<a href="#">NPR</a>	IY	<a href="#">147-3758</a>	00	001	COUPLING GP-GENERATOR
		I	PA5935	01	001	588 FRAME GENERATOR REMOVAL
	<a href="#">NPR</a>	IY	<a href="#">6I-2026</a>	04	001	CONNECTION GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">5N-2975</a>	05	001	INSTALLATION AR-GENERATOR
		I	PA5942	01	001	GENERATOR 592 FRAME PM
	<a href="#">NPR</a>	IY	<a href="#">9Y-0447</a>	01	001	GENERATOR AR
	<a href="#">NPR</a>	IY	<a href="#">108-1467</a>	00	001	COUPLING GP-GENERATOR
		I	PA6011	00	001	LIGHT DUTY AIR CLEANER REMOVAL
	<a href="#">NPR</a>	IY	<a href="#">8N-3110</a>	06	001	AIR CLEANER GP
		I	PA5344	01	001	CHARGING ALTERNATOR 24V 35 AMP

	<a href="#">NPR</a>	IY	<a href="#">4P-4063</a>	01	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IRY	<a href="#">6T-1395</a>	06	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY	<a href="#">7E-9054</a>	03	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">103-7286</a>	01	001	MOUNTING GP-CIRCUIT BREAKER
		I	PA5020	04	001	2301A LOAD SHARING GOVERNOR
	<a href="#">NPR</a>	IY	<a href="#">6N-4703</a>	12	001	FASTENER GP-GOVERNOR
	<a href="#">NPR</a>	IRY	<a href="#">7W-6653</a>	03	001	ACTUATOR AS-GOVERNOR
	<a href="#">NPR</a>	IY	<a href="#">7W-6542</a>	06	001	CONTROL GP-GOVERNOR
		I	3L-0303		001	ADJUSTING-WW 2301 CONTROL SYS
		I	PA3371	00	001	RADIATOR AR - OPTIONAL
	<a href="#">NPR</a>	IY	<a href="#">4N-3465</a>	11	001	FAN GP-BLOWER
	<a href="#">NPR</a>	IY	<a href="#">6N-3651</a>	03	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">6N-9929</a>	01	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">7N-8842</a>	01	001	DRIVE GP-FAN
	<a href="#">NPR</a>	IY	<a href="#">7N-9951</a>	11	001	RADIATOR GP
	<a href="#">NPR</a>	IY	<a href="#">111-3794</a>	00	001	SENSOR GP-COOLANT LEVEL
	<a href="#">NPR</a>	IY	<a href="#">4P-1788</a>	01	001	KIT-SPACE HEATER
	<a href="#">NPR</a>	IY	<a href="#">121-4712</a>	01	001	PANEL GP-ELECTRONIC
	<a href="#">NPR</a>	IY	<a href="#">134-1157</a>	00	001	RELAY GP
	<a href="#">NPR</a>	IY	<a href="#">9Y-6496</a>	02	001	MODULE GP-INTERFACE
	<a href="#">NPR</a>	IY	<a href="#">121-4716</a>	01	001	MODULE GP-ALARM
	<a href="#">NPR</a>	IY	<a href="#">7C-5296</a>	01	001	PANEL GP-INSTRUMENT
	<a href="#">NPR</a>	IY	<a href="#">109-7755</a>	02	001	FUMES DISPOSAL GP
	<a href="#">NPR</a>	IY	<a href="#">8N-9561</a>	01	001	MOUNTING GP-ENGINE
	<a href="#">NPR</a>	IY	<a href="#">7E-4266</a>	00	001	MOUNTING GP-GENERATOR
		I	PA0765	04	001	JACKET WATER HEATER
	<a href="#">NPR</a>	IY	<a href="#">7W-3867</a>	07	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">7E-6248</a>	05	001	HEATER GP-JACKET WATER
		I	PL2400	01	001	BATTERY & RACK GP-INSTALLED
	<a href="#">NPR</a>	IY	<a href="#">5N-2284</a>	04	001	SUPPORT GP-BATTERY
	<a href="#">NPR</a>	IY	<a href="#">7L-7872</a>	08	001	BATTERY GP
	<a href="#">NPR</a>	IY	<a href="#">7W-0825</a>	01	001	CABLE GP-BATTERY
		I	PA5614	00	001	CIRCUIT BREAKER MOUNTING
	<a href="#">NPR</a>	IY	<a href="#">4P-4968</a>	00	001	MOUNTING GP-CIRCUIT BREAKER
	<a href="#">NPR</a>	IY	<a href="#">4P-4969</a>	01	001	BOX GP-EXTENSION TERMINAL
	<a href="#">NPR</a>	IY	<a href="#">106-9697</a>	00	001	NEUTRAL BUS BAR AS
	<a href="#">NPR</a>	IY	<a href="#">108-1055</a>	00	001	FASTENER GP-EXTENSION BOX
	<a href="#">NPR</a>	IY	<a href="#">108-1056</a>	00	001	COVER GP-EXTENSION BOX
		I	121-4713	00	001	INSTRUCTIONS
		I	0P-9715		001	EXTRA LITERATURE - ENGLISH



I	0P-1530		001	GENERATOR TEST REPORT
I	0P-1853		001	GEN SET TEST CHARGE
I	0P-7513		001	0P7513 STANDBY PLUS PGM344
I	0P-9013		001	0P9013 PRE01JUL97PRCPGM641-4
I	PL8681	03	001	749 BHP 515 GEN KW WOF 60HZ
I	0T-6188	00	001	558.5 KW @ 1800 RPM (749 BHP)
I	0P-8709		001	STANDBY ALLOW PGM - PGM 344