

3306B GEN SET ENGINE

Engine Serial Prefix - 9NR (Build Date - 01/2002, Test Date - 02/2002, Ship Date - 02/2002)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (9NR)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00230	F	001	230 EKW W/FAN
		I	306DE35	F	001	3306 480 VOLT 60 HZ PGS
		I	OGNPM07	F	001	GENERATOR 445 FRAME PM
		I	RPA0007	F	001	GENERATOR REMOVAL
		I	GOVEL01	F	001	1724 ELECTRONIC GOVERNOR
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCRH01	F	001	RH MTG OF CONTROL PANEL
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	EMCEFR1	F	001	RELAY GP
		I	ACT0001	F	001	EXTENDED LIFE COOLANT
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	BTC0501	F	001	BATTERY CHARGER 5 AMP
		I	ALT2409	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	NSB0001	F	001	NARROW BASE
		I	CBK3P10	F	001	400 AMP 3 POLE CIRCUIT BREAKER
		I	BAT2403	F	001	24 VOLT BATTERY SET - DRY
		I	BTRCBL1	F	001	BATTERY CABLES
		I	BTR0001	F	001	BATTERY RACK
		I	JWH0001	F	001	JACKET WATER HEATER
		I	ACLLD01	F	001	AIR CLEANER - LIGHT DUTY
		I	FLN0002	F	001	FLEXIBLE FUEL LINES
		I	FWS0001	F	001	WATER SEPARATOR
		I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG

	I	STANDBY	F	001	STANDBY POWER APPLICATION
	I	CBKRH01	F	001	RH MOUNT CIRCUIT BREAKER
	I	NONCERT	F	001	NON-CERTIFIED
	I	NONULL	F	001	NON UL 2200 LISTED PKG GEN SET
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
	I	0P-8910	F	001	IU96-405_ POST SALE SPAR
					PART NUMBERS
	I	PP3669	03	001	343 BHP 236 GEN KW WOF 60 HZ S
	I	PA6786	02	001	3306 480 VOLT 60 HZ PGS
	NPR	IY 132-5400	02	001	ENGINE AR
	NPR	IY 2W-8198	09	001	SHUTOFF GP-ELECTRICAL
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	NPR	IY 3N-7210	05	001	DRIVE GP-FAN
	NPR	IY 4P-7610	03	001	SENSOR GP-SPEED
	I	5N-7601		001	AUTHORIZED APPROVAL NUMBER
	I	5P-2506	00	001	LITERATURE GP
	NPR	I 5P-2586	03	001	OIL
	NPR	IY 6I-1888	02	001	PULLEY GP-FAN DRIVE
	NPR	IY 6L-2927	08	001	ELBOW GP-EXHAUST
	NPR	IY 7N-8756	02	001	LINES GP-AIR
	NPR	IY 8N-0888	10	001	REGULATOR GP-TEMPERATURE
	NPR	IY 9L-5065	08	001	STARTING MOTOR GP-ELECTRIC
	NPR	IY 102-9976	00	001	MOUNTING GP-CONTACTOR
	NPR	IY 103-1949	02	001	WIRING GP-PANEL
	NPR	IY 103-6101	04	001	CONTROL GP-ENGINE MONITORING
	NPR	IY 104-4704	03	001	MOUNTING GP-CONTROL PANEL
	NPR	IY 109-3319	03	001	COUPLING GP-GENERATOR
	NPR	IY 112-1509	02	001	FUMES DISPOSAL GP
	NPR	IY 129-6803	03	001	CONNECTION GP-ELECTRICAL
	NPR	IY 129-7503	02	001	LINES GP-ENGINE OIL DRAIN
	NPR	IY 130-3480	02	001	MOUNTING GP-VOLTAGE REGULATOR
	NPR	IY 133-9527	01	001	LINES GP-COOLANT DRAIN
	NPR	IY 144-6585	02	001	RADIATOR GP
	I	3L-0284		001	*****TEST - PKG GEN SET*****
	I	CA0343	00	001	GENERATOR 445 FRAME PM
	NPR	IY 129-1498	00	001	GENERATOR AR

	NPR	IY	130-3649	01	001	REGULATOR GP-VOLTAGE
		I	CA0363	00	001	GENERATOR REMOVAL
		I	PA5015	02	001	1724 ELECTRONIC GOVERNOR
	NPR	IY	7E-0598	00	001	ACTUATOR AS-GOVERNOR
	NPR	IY	9Y-6375	02	001	MOUNTING GP-GOVERNOR ACTUATOR
	NPR	IY	131-5455	02	001	CONTROL AS-GOVERNOR
		I	121-4713	00	001	INSTRUCTIONS
		I	PL4838	04	001	RH MTG OF CONTROL PANEL
		I	5N-7563		001	NOTE- CONTROL PANEL MTG (RH)
	NPR	IY	121-4716	01	001	MODULE GP-ALARM
	NPR	IY	121-4712	01	001	PANEL GP-ELECTRONIC
	NPR	IY	134-1157	00	001	RELAY GP
		I	CA0561	00	001	LONG LIFE COOLANT/ANTIFREEZE
	NPR	I	119-5148	01	001	COOLANT-EXTENDED LIFE
	NPR	IY	165-6634	02	001	SENSOR GP-COOLANT LEVEL
	NPR	IY	7C-9141	03	001	BATTERY CHARGER
		I	CA0591	02	001	CHARGING ALTERNATOR 24V 35 AMP
	NPR	IY	7C-5024	01	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	IY	7E-5073	02	001	ALTERNATOR GP-CHARGING
	NPR	IY	137-4313	01	001	GUARD GP-ALTERNATOR
		I	CA0453	00	001	NARROW BASE
	NPR	IY	128-2349	00	001	BASE GP-ENGINE
		I	CA0412	03	001	CIRCUIT BREAKER W/ST 400 AMP
	NPR	IY	6I-3340	00	001	NEUTRAL BUS BAR AS
	NPR	IY	105-7185	01	001	HARNESS AS-PANEL
	NPR	IY	129-5841	00	001	COVER GP-GENERATOR
	NPR	IY	130-2572	01	001	BOX GP-EXTENSION TERMINAL
	NPR	IY	130-2569	00	001	FASTENER GP-EXTENSION BOX
		I	5N-9690		001	NOTE-CIRCUIT BREAKER TRIP-400A
	NPR	IY	169-1837	00	001	CIRCUIT BREAKER GP
	NPR	IY	169-1851	01	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	IY	160-5447	00	001	BATTERY GP
	NPR	IY	7W-0825	01	001	CABLE GP-BATTERY
	NPR	IY	3N-7056	00	001	SUPPORT GP-BATTERY
		I	CA0455	01	001	JACKET WATER HEATER
	NPR	IY	7E-6247	03	001	HEATER GP-JACKET WATER

	NPR	IY	129-4438	01	001	MOUNTING GP-JACKET WTR HEATER
		I	CA0447	02	001	AIR CLEANER - LIGHT DUTY
	NPR	IY	9Y-2201	00	001	AIR CLEANER GP
	NPR	IY	5N-0410	04	001	LINES GP-FLEXIBLE FUEL
	NPR	IY	112-1171	02	001	SEPARATOR GP-WATER
	NPR	IY	3N-7442	05	001	SWITCH AS-TEMPERATURE
		I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
		I	0V-1065		001	0V1065 ENDUSE:GENERAL EPG
		I	9Y-8156		001	STANDBY POWER APPLICATION
		I	5N-7595		001	NOTE - MOUNT CIRCUIT BKR RH
		I	PP3669	03	001	343 BHP 236 GEN KW WOF 60 HZ S
	NPR	IY	131-3534	01	001	PUMP GP-GOV & FUEL INJ
		I	2T-8486	01	001	256 KW @ 1800 RPM (343 BHP)
						SHIPPED LOOSE
	NPR	S	2V-7397		001	CABLE AS
	NPR	S	3J-7352		001	CONNECTOR
	NPR	S	3J-7354		001	SEAL-O-RING
	NPR	S	3K-0360		001	SEAL-O-RING
	NPR	S	3K-1715		001	CABLE AS
	NPR	S	3N-7054		001	SUPPORT AS-BATTERY
	NPR	S	3N-7055		001	BOARD
	NPR	S	3N-8097		001	HOSE AS
	NPR	S	3N-8098		001	HOSE AS
	NPR	S	3V-6785		001	CABLE AS
		S	4N-6021		001	DIAGRAM-WIRING
	NPR	S	4W-6413		001	FILM-MAINTENANCE
	NPR	SY	7C-9141		001	BATTERY CHARGER
		S	7L-5912		001	DIAGRAM-WIRING
	NPR	S	7N-5274		001	COVER AS-TERMINAL
	NPR	S	8L-8413		004	STRAP-CABLE
	NPR	S	8N-0869		001	COVER-TERMINAL
	NPR	S	8N-1725		001	COVER AS-TERMINAL
	NPR	S	9G-0003		002	COVER AS-TERMINAL
	NPR	S	9G-0004		002	COVER AS-TERMINAL
	NPR	S	9G-8909		001	COVER-TERMINAL
		S	REHS0753		001	WARR REGISTRATION 140010D2(A)

<input type="checkbox"/>	S	SEBP2532	001	PTSBK SAM (A)
<input type="checkbox"/>	S	SEBP2534	001	PT BK(EMCP 11) 1686 2-7(A)
<input type="checkbox"/>	S	SEBU6042	002	SUPP
<input type="checkbox"/>	S	SEBU6251	001	LUBE
<input type="checkbox"/>	S	SEBU6918	002	OMM
<input type="checkbox"/>	S	SEBU6984	001	SUPP
<input type="checkbox"/>	S	SEBU6998	001	OMM 1632-10 (A)
<input type="checkbox"/>	S	SELF5326	001	WARRANTY
<input type="checkbox"/>	S	SELS0180	001	S.I. (A)
<input type="checkbox"/>	S	SELS0206	001	S.I. (A)
<input type="checkbox"/>	S	SENR4794	001	SCHEMATIC
<input type="checkbox"/>	S	SMBU6981	001	SUPP
<input type="checkbox"/>	NPR	S 005-4362	001	ELBOW
<input type="checkbox"/>	NPR	S 115-2421	002	BATTERY GP

Key:

I Installed

Y Separate Illustration

S Shipped Loose