

3516B GEN SET ENGINE

Engine Serial Number - 2JW (Build Date - 08/2000, Test Date - 08/2000, Ship Date - 08/2000)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (2JW)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
<input type="checkbox"/>		I	KW01600	F	001	1600 EKW W/FAN
<input type="checkbox"/>		I	516DE74	F	001	3516B 1825 EKW 50 HZ LO BSFC
<input type="checkbox"/>		I	EMCPLUS	F	001	EMCP TWO PLUS
<input type="checkbox"/>		I	EMCMETU	F	001	METRIC DISPLAY UNITS
<input type="checkbox"/>		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
<input type="checkbox"/>		I	EMCAM03	F	001	CUSTOM ALARM MODULE
<input type="checkbox"/>		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
<input type="checkbox"/>		I	EMCEFR1	F	001	RELAY GP
<input type="checkbox"/>		I	CLSSTND	F	001	COOLANT LOSS SENSING
<input type="checkbox"/>		I	CCM0001	F	001	CUST COMMUNICATIONS MODULE-CCM
<input type="checkbox"/>		I	SHREL01	F	001	SPACE HEATER RELAY
<input type="checkbox"/>		I	VIBIS05	F	001	VIBRATION ISOLATORS
<input type="checkbox"/>		I	EXCFF14	F	001	FLEXIBLE FITTING
<input type="checkbox"/>		I	JWHD001	F	001	JACKET WATER HEATER - DUAL
<input type="checkbox"/>		I	FPPRH01	F	001	FUEL PRIMING PUMP, RH MOUNTED
<input type="checkbox"/>		I	LUBOIL1	F	001	LUBRICATING OIL
<input type="checkbox"/>		I	BTC1006	F	001	BATTERY CHARGER 10 AMP
<input type="checkbox"/>		I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
<input type="checkbox"/>		I	RRM0043	F	001	RADIATOR REMOVAL 60/CV, 0.422
<input type="checkbox"/>		I	SCACCV1	F	001	SCAC CONVERSION
<input type="checkbox"/>		I	CLFLCN1	F	001	FLANGED CONNECTION
<input type="checkbox"/>		I	DFFRH01	F	001	DUPLEX FUEL FILTER RH
<input type="checkbox"/>		I	DUOILF0	F	001	RH DUPLEX OIL FILTER
<input type="checkbox"/>		I	50H-0400	F	001	50HZ 400 VOLTS
<input type="checkbox"/>		I	MSEPGGN	F	001	GENERAL EPG (NON-ENCLOSED)
<input type="checkbox"/>		I	SWP0001	F	001	SHRINK WRAP PROTECTION - 3516

	I	TRSGEN2	F	001	PGS TEST REPORT @ 1.0 PF	
	I	LITENGE	F	003	EXTRA ENGLISH LITERATURE	
	I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT	
	I	LOWBSFC	F	001	LO BSFC	
	I	50HERTZ	F	001	50 HERTZ	
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL	
	I	3516B	F	001	3516B DIESEL ENGINE	
	I	CONTINU	F	001	CONTINUOUS APPLICATION	
	I	NORAD	F	001	NO RADIATOR	
	I	XLLENGL	F	001	EXTRA ENGLISH LITERATURE	
					<b>PART NUMBERS</b>	
	I	LL5362	02	001	2307 BHP 1600 GEN KW W/F 50 HZ	
	I	LA2662	05	001	ENGINE AR-3516B-DITA-PGS 50 HZ	
	<u>NPR</u>	IY <a href="#">129-3093</a>	06	001	ENGINE AR	
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II)	
	I	3L-0456		001	PROCEDURE - DVR PROG AND TEST	
	I	3L-0467		001	TWO BEARING GEN ALIGNMENT-3500	
	<u>NPR</u>	I	5N-2438	05	001	LINES GP-FLEXIBLE FUEL
	I	5N-9582		001	LOW BSFC STRATEGY	
	I	5P-2506	00	001	LITERATURE GP	
	<u>NPR</u>	IY <a href="#">7C-0527</a>	02	001	STARTING MOTOR GP-ELECTRIC	
	<u>NPR</u>	IY <a href="#">7N-6782</a>	08	001	INDICATOR GP-AIR FILTER CHANGE	
	<u>NPR</u>	IY <a href="#">8N-9639</a>	04	001	GUARD GP-DAMPER	
	<u>NPR</u>	IRY <a href="#">9X-9591</a>	01	001	CONVERTER GP-ELECTRICAL	
	<u>NPR</u>	I	104-4704	03	001	MOUNTING GP-CONTROL PANEL
	<u>NPR</u>	IY <a href="#">113-1581</a>	00	001	AIR CLEANER GP	
	<u>NPR</u>	IY <a href="#">115-3613</a>	02	001	MOUNTING GP-AIR CLEANER	
	<u>NPR</u>	I	115-7046	01	001	RAIL GP-ENGINE SUPPORT
	<u>NPR</u>	I	121-4450	10	001	PANEL GP-CONTROL
	<u>NPR</u>	I	121-6202	06	001	REGULATOR GP-VOLTAGE
	<u>NPR</u>	I	121-8856	06	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY <a href="#">126-9191</a>	02	001	GROUND GP-ELECTRICAL	
	<u>NPR</u>	IY <a href="#">134-0061</a>	04	001	WIRING GP-ENGINE	
	<u>NPR</u>	I	141-1809	01	001	BOX GP-GENERATOR CONNECTION
	<u>NPR</u>	I	145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
	<u>NPR</u>	IY <a href="#">166-7142</a>	02	001	INSTALLATION AR-GENERATOR	

	<a href="#">NPR</a>	I	144-1828	03	001	GENERATOR AR
	<a href="#">NPR</a>	IY	<a href="#">195-0958</a>	01	001	MOUNTING GP-ENGINE OIL FILTER
		IY	<a href="#">158-6167</a>	03	001	CONVERSION AR
		I	121-4714	00	001	UNITS AS-METERIC
	<a href="#">NPR</a>	IY	<a href="#">121-4716</a>	01	001	MODULE GP-ALARM
	<a href="#">NPR</a>	IY	<a href="#">131-1958</a>	01	001	MODULE GP-ALARM
	<a href="#">NPR</a>	IY	<a href="#">121-4712</a>	01	001	PANEL GP-ELECTRONIC
	<a href="#">NPR</a>	I	134-1157	00	001	RELAY GP
		I	139-1129	00	001	COOLANT LOSS SENSING
	<a href="#">NPR</a>	IY	<a href="#">102-8627</a>	01	001	MODULE GP-SYSTEM COMMUNICATION
	<a href="#">NPR</a>	I	122-0335	02	001	RELAY GP
	<a href="#">NPR</a>	IY	<a href="#">5N-8877</a>	04	001	MOUNTING GP-ENGINE FLEXIBLE
		I	LA0568	04	001	FLEXIBLE FITTINGS
	<a href="#">NPR</a>	IY	<a href="#">5N-2457</a>	03	001	FITTING GP-EXHAUST
		I	PA4355	05	001	JACKET WATER HEATER - DUAL
	<a href="#">NPR</a>	IY	<a href="#">7E-6247</a>	03	001	HEATER GP-JACKET WATER
	<a href="#">NPR</a>	IY	<a href="#">6I-1043</a>	03	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">6I-1044</a>	07	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">115-1063</a>	02	001	PUMP GP-FUEL PRIMING
		I	PA5313	05	001	LUBRICATING OIL
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
	<a href="#">NPR</a>	IY	<a href="#">7C-3874</a>	02	001	BATTERY CHARGER
		I	LA0427	08	001	CHARGING ALTERNATOR 24V 35AMP
	<a href="#">NPR</a>	IY	<a href="#">7C-4803</a>	02	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY	<a href="#">7E-4836</a>	05	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IY	<a href="#">7W-5780</a>	04	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">107-7361</a>	01	001	DRIVE GP-ACCESSORY
	<a href="#">NPR</a>	IY	<a href="#">133-6468</a>	01	001	WIRE AS-GROUND
		I	LA2666	00	001	RADIATOR REMOVAL AR-60 CV/.422
		I	LA2418	03	001	SCAC CONVERSION
	<a href="#">NPR</a>	IY	<a href="#">9Y-8175</a>	03	001	PUMP GP-AUXILIARY WATER
	<a href="#">NPR</a>	IY	<a href="#">116-7004</a>	02	001	REGULATOR GP-TEMPERATURE
	<a href="#">NPR</a>	IY	<a href="#">112-2668</a>	06	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">115-7850</a>	05	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">4P-7072</a>	00	001	CONNECTION GP-WATER
	<a href="#">NPR</a>	I	121-0470	04	001	FILTER GP-FUEL

	<a href="#">NPR</a>	IY	<a href="#">120-4501</a>	05	001	FILTER GP-ENGINE OIL
		I	5N-9590		001	VOLTAGE INDICATOR - 400 VOLT
		I	0V-1065		001	END USE: GENERAL EPG
		I	0P-7607		001	SHRINK WRAP PROTECTION - 3516
		I	0P-1910		001	CHARGE FOR STD. GEN SET TEST
		I	0P-9715		003	EXTRA LITERATURE - ENGLISH
		I	0P-1914		001	DOMESTIC PACK FOR EXPORT
		I	LL5362	02	001	2307 BHP 1600 GEN KW W/F 50 HZ
		I	OK-2494	00	001	1720 KW @ 1500 RPM (2307 BHP)
						<b>SHIPPED LOOSE</b>
	<a href="#">NPR</a>	S	0S-1571		016	BOLT
	<a href="#">NPR</a>	S	0S-1588		016	BOLT
	<a href="#">NPR</a>	S	3N-6504		001	HOSE AS
	<a href="#">NPR</a>	S	3V-3308		016	WASHER-HARD
	<a href="#">NPR</a>	S	5F-5990		002	CLIP
	<a href="#">NPR</a>	S	5L-3773		002	GASKET-EXHAUST ELBOW
	<a href="#">NPR</a>	S	5L-6297		002	ADAPTER AS-FLEXIBLE
	<a href="#">NPR</a>	S	5P-7197		008	WASHER
	<a href="#">NPR</a>	SY	<a href="#">7C-3874</a>		001	BATTERY CHARGER
	<a href="#">NPR</a>	S	8N-1186		001	HOSE AS
	<a href="#">NPR</a>	S	9S-8752		016	NUT-FULL
	<a href="#">NPR</a>	S	153-3864		008	MOUNT AS
	<a href="#">NPR</a>	SRV	<a href="#">164-8940</a>		001	MODULE GP-SYSTEM COMMUNICATION
	<a href="#">NPR</a>	S	171-6719		001	KIT-PARTS
	<a href="#">NPR</a>	S	171-6721		001	KIT-PARTS
		S	JERC2162		001	SOFT
		S	SEBP2414		004	PTSBK
		S	SEBP2979		004	PTSBK
		S	SEBU6042		004	SUPP (GEN ONLY) 1632-05 (A)
		S	SEBU6251		004	LUBE
		S	SEBU6874		001	OMM
		S	SEBU6918		004	OMM(GEN ONLY) FL CC06E(A)
		S	SEBU7252		004	OMM
		S	SELF5308		004	WARRANTY 140013C2(A)
		S	SELS0086		004	S.I.
		S	SENR4794		004	DIAGRAM 1634-04 (A)



S	SMBU6908	001	NO FRGN OMM LAN
S	ESO	001	(PRNT ESO COPY)
S	PML	001	*REQUIRED DECALS