

ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1972	1973	1974	1975
2-71	(2A)	85087	86279	88906	92258
3-71	(3A)	79536	80506	81772	83322
4-71	(4A)	175996	182907	192267	201395
6-71	(6A)	248936	272037	295884	317658
12-71	(12A)	7599	-	-	-
24-71	(24A)	568	-	-	-
2-53	(2D)	31648	-	-	-
3-53	(3D)	92337	103048	114363	126016
4-53	(4D)	81979	91891	104147	118187
6V-53	(6D)	84457	93545	104554	117870
8V-53	(8D)	5056	5779	6508	-
8.2	(8G)	-	-	-	-
12V-149	(12E)	1511	1797	2441	3308
16V-149	(16E)	258	406	2258	2715
6V-71	(6VA)	63698	68936	76103	83893
8V-71	(8VA)	164953	212755	263580	312998
12V-71	(12VA)	27217	31036	35732	42694
16V-71	(16VA)	7091	7696	8793	10414
6V-92	(6VF)	-	-	330	753
8V-92	(8VF)	-	-	608	3000
12V-92	(12VF)	-	-	-	-
16V-92	(16VF)	-	-	-	1014
3-53	(DB)*	-	-	-	-
4-53	(DB)*	-	-	-	-
6V-53	(DB)*	-	-	-	-

* = Series 53 Brazilian engines

† = V71 Vauxhall Engines

ENGINE SERIAL NUMBER GUIDE

ENGINE SERIAL NUMBER GUIDE (Serial number of first engine built in year)					
Engine	Serial Number Suffix	1972	1973	1974	1975
6V-71†	(6VW)	-	-	-	-
8V-71†	(8VW)	-	-	-	-

* = Series 53 Brazilian engines

† = V71 Vauxhall Engines

ENGINE SERIAL NUMBER GUIDE (Serial number of first engine built in year)					
Engine	Serial Number Suffix	1976	1977	1978	1979
2-71	(2A)	96031	98179	99832	102060
3-71	(3A)	85360	86622	88356	91254
4-71	(4A)	211904	217942	226719	235791
6-71	(6A)	332518	346750	363474	383376
12-71	(12A)	-	-	-	-
24-71	(24A)	-	-	-	-
2-53	(2D)	-	-	-	-
3-53	(3D)	132996	140042	149459	156459
4-53	(4D)	130979	142705	153389	163134
6V-53	(6D)	137232	150301	164924	177379
8V-53	(8D)	-	6757 <i>W</i>	6779	-
8.2	(8G)	-	-	-	870
12V-149	(12E)	4136	4516	5118	5542
16V-149	(16E)	3388	3784	4325	5072
6V-71	(6VA)	90735	96214	102397	109395
8V-71	(8VA)	332778	352434	370909	387198
12V-71	(12VA)	47948	51768	56934	62224
16V-71	(16VA)	12225	13472	15078	16154
6V-92	(6VF)	1163	7597	21033	29536
8V-92	(8VF)	4398	8331	18770	34236
12V-92	(12VF)	-	-	-	603

(Serial number of first engine built in year)

Engine	Serial Number Suffix	1976	1977	1978	1979
16V-92	(16VF)	1149	1360	2033	2773
3-53	(DB)*	-	-	1631	4238
4-53	(DB)*	-	6103	30611	45568
6V-53	(DB)*	-	-	1501	6057
6V-71	(6VW)†	-	-	740	951
8V-71	(8VW)†	-	-	3496	4605

* = 53 Brazilian engines

† = V-71 Vauxhall engines

ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Models	Serial Number Suffix	1980	1981	1982	1983
2-71	(2A)	103084	104064	105345	105938
3-71	(3A)	93850	96585	98903	99743
4-71	(4A)	244142	252368	260660	265225
6-71	(6A)	402393	414833	426666	431867
12-71	(12A)	-	-	-	-
24-71	(24A)	-	-	-	-
2-53	(2D)	-	-	-	-
3-53	(3D)	165142	173980	183686	187591
4-53	(4D)	173284	185204	197307	201552
6V-53	(6D)	189278	203804	213393	220648
8V-53	(8D)	-	-	-	-
8.2	(8G)	2380	26314	49621	67726
12V-149	(12E)	5902	6337	7807	8097
16V-149	(16E)	5546	6225	7070	7506
6V-71	(6VA)	114948	121419	127934	130333
8V-71	(8VA)	403649	414883	424827	429985
12V-71	(12VA)	66325	70811	75323	76898

* = Brazilian engines

‡ = Last Unit built

† = V71 Vauxhall engines

ENGINE SERIAL NUMBER GUIDE (Serial number of first engine built in year)					
Models	Serial Number Suffix	1980	1981	1982	1983
16V-71	(16VA)	16815	17665	18647	18997
6V-92	(6VF)	59288	75269	87940	98800
8V-92	(8VF)	56967	66994	75197	81446
12V-92	(12VF)	605	690	1079	1358
16V-92	(16VF)	3470	4517	5698	6060
3-53	(DB)*	5326‡	-	-	-
4-53	(DB)*	53632‡	-	-	-
6V-53	(DB)*	7186‡	-	-	-
6V-71	(6VW)†	1160	1691	-	-
8V-71	(8VW)†	5302	6023	-	-

* = Brazilian engines

‡ = Last Unit built

† = V71 Vauxhall engines

ENGINE SERIAL NUMBER GUIDE (Serial number of first engine built in year)					
Models	Serial Number Suffix	1984	1985	1986	1987
2-71	(2A)	106014	106114	106233	-
3-71	(3A)	100419	1010291	101386	101649
4-71	(4A)	283732	268457	273305	277157
6-71	(6A)	437367	444805	450007	454231
3-53	(3D)	192100	198002	201788	204163
4-53	(4D)	206188	211860	215845	218846
6-53	(6D)	226970	232563	237118	240091
8.2L	(8G)	90548	116572	145645	169919
8V-149	(8E)	2502	2516	2533	2554
12V-149	(12E)	8193	8596	8761	8878
16V-149	(16E)	7780	8288	8555	8800
S60	(6R)	-	-	46	641*

* = Production engines began with 1000 numbers March of 1987.

All engine numbers less than 1000 were prototypes

(Serial Number Suffix)

Models	Serial Number Suffix	1984	1985	1986	1987
6V-71	(6VA)	132764	134457	136777	138249
8V-71	(8VA)	433763	438112	441455	444781
12V-71	(12VA)	77992	79193	80439	81348
16V-71	(16VA)	19254	19438	19555	19691
6V-92	(6VF)	-	124769	138252	147899
8V-92	(8VF)	87677	99597	109240	116454
12V-92	(12VF)	1579	1854	2095	2418
16V-92	(16VF)	6184	6521	6728	6942

* = Production engines began with 1000 numbers March of 1987.
All engine numbers less than 1000 were prototypes.

ENGINE SERIAL NUMBER GUIDE

(Serial number of first engine built in year)

Models	Serial Number Suffix	1988	1989	1990	1991
2-71	(2A)	-	-	-	-
3-71	(3A)	101790	102098	102380	102619
4-71	(4A)	278921	28125	283732	285367
6-71	(6A)	458175	461334	463867	466239
3-53	(3D)	205630	207447	208728	209719
4-53	(4D)	221369	223855	225902	227378
6V-53	(6D)	244387	247601	250817	253379
8.2L	(8G)	194394	214557	230813	300010
8V-149	(8E)	2594	2632	2654	2680
12V-149	(12E)	8962	9153	9376	9663
16V-149	(16E)	9026	9435	10037	10706
20V-149	(20E)	-	-	-	-
S60	(6R)	2489	7912	19370	36682
S50	(4R)	-	-	-	-
6V-71	(6VA)	139512	140642	141280	141688
8V-71	(8VA)	447118	449111	450085	451040
12V-71	(12VA)	82196	83332	84317	85241
16V-71	(16VA)	19767	19868	19974	20063
6V-92	(6VF)	157536	165978	176967	185719
8V-92	(8VF)	123521	130586	137828	143409
12V-92	(12VF)	2892	3683	4657	5645
16V-92	(16VF)	7376	7852	8624	9361

2-71	(2A)	-	
3-71	(3A)	102813	102396
4-71	(4A)	286290	287128
6-71	(6A)	467847	469561
3-53	(3D)	210623	211669
4-53	(4D)	228305	229137
6V-53	(6D)	256278	258413
DD 500	(8G)	300134	300269
8V-149	(8E)	2714	2784
12V-149	(12E)	9873	10130
16V-149	(16E)	11184	11592
20V-149	(20E)	200012	200020
S50	(4R)	1001	1359
S60	(6R)	67287	107892
6V-71	(6VA)	142124	142478
8V-71	(8VA)	452007	452670
12V-71	(12VA)	85948	86899
16V-71	(16VA)	20123	20192
6V-92	(6VF)	193422	200371
8V-92	(8VF)	150345	155992
12V-92	(12VF)	6641	7609
16V-92	(16VF)	10082	10945