

ENGINE - ENTIRE GROUP (2WJ01253)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
		I	PA5361	03	001	3412 800 EKW 60 HZ PGS-STBY
	<a href="#">NPR</a>	IY	<a href="#">7E-1091</a>	11	001	ENGINE AR
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	<a href="#">NPR</a>	IY	<a href="#">3N-6668</a>	05	001	LINES GP-FLEXIBLE FUEL
	<a href="#">NPR</a>	IY	<a href="#">4N-1061</a>	14	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">4P-7610</a>	02	001	SENSOR GP-SPEED
		I	5N-7562	00	001	CHART
		I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
	<a href="#">NPR</a>	IY	<a href="#">6I-2026</a>	04	001	CONNECTION GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">7E-9053</a>	01	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">9Y-6397</a>	04	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	IY	<a href="#">102-9942</a>	00	001	MOUNTING GP-CONTACTOR
	<a href="#">NPR</a>	IY	<a href="#">103-1966</a>	05	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	IY	<a href="#">104-4704</a>	03	001	MOUNTING GP-CONTROL PANEL
	<a href="#">NPR</a>	IY	<a href="#">106-3581</a>	01	001	GENERATOR AR
	<a href="#">NPR</a>	IY	<a href="#">108-1467</a>	00	001	COUPLING GP-GENERATOR
	<a href="#">NPR</a>	IY	<a href="#">6N-8878</a>	02	001	GAUGE GP-FUEL PRESSURE
	<a href="#">NPR</a>	IY	<a href="#">7E-4254</a>	00	001	AIR CLEANER GP
		I	5N-9677		001	NOTE-PANEL CHART 1369048
		I	PA5610	01	001	RADIATOR E 0.571 DRIVE
	<a href="#">NPR</a>	IY	<a href="#">6N-4371</a>	02	001	FAN GP-BLOWER
	<a href="#">NPR</a>	IY	<a href="#">6N-4874</a>	03	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">7E-4257</a>	02	001	RADIATOR GP
	<a href="#">NPR</a>	IY	<a href="#">7E-4259</a>	00	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">7N-8849</a>	01	001	DRIVE GP-FAN
	<a href="#">NPR</a>	IY	<a href="#">111-3794</a>	00	001	SENSOR GP-COOLANT LEVEL
	<a href="#">NPR</a>	IY	<a href="#">121-4712</a>	01	001	PANEL GP-ELECTRONIC
	<a href="#">NPR</a>	IY	<a href="#">121-4716</a>	01	001	MODULE GP-ALARM
		I	PA5399	00	001	JACKET WATER HEATER
	<a href="#">NPR</a>	IY	<a href="#">7E-4244</a>	01	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">7E-6248</a>	05	001	HEATER GP-JACKET WATER

**PART NUMBERS**

<a href="#">NPR</a>	IY	<a href="#">7L-7872</a>	08	001	BATTERY GP
<a href="#">NPR</a>	IY	<a href="#">9Y-6496</a>	02	001	MODULE GP-INTERFACE
<a href="#">NPR</a>	IY	<a href="#">116-7846</a>	03	001	REGULATOR GP-VOLTAGE
	I	PL1697	05	001	PRIMARY FUEL FILTER
<a href="#">NPR</a>	IY	<a href="#">6N-3212</a>	04	001	MOUNTING GP-PRIMARY FUEL FLTR
<a href="#">NPR</a>	IY	<a href="#">8H-7204</a>	09	001	FILTER GP-FUEL
	I	PA5346	01	001	CHARGING ALTERNATOR 24V 45 AMP
<a href="#">NPR</a>	IY	<a href="#">4P-4061</a>	01	001	MOUNTING GP-ALTERNATOR
<a href="#">NPR</a>	IRY	<a href="#">5N-5692</a>	11	001	ALTERNATOR GP-CHARGING
<a href="#">NPR</a>	IY	<a href="#">7E-9054</a>	03	001	GUARD GP-BELT
<a href="#">NPR</a>	IY	<a href="#">103-7286</a>	01	001	MOUNTING GP-CIRCUIT BREAKER
	I	PA5396	01	001	VIBRATION ISOLATORS
<a href="#">NPR</a>	IY	<a href="#">8N-9562</a>	01	001	MOUNTING GP-ENGINE
<a href="#">NPR</a>	I	8N-9955	00	001	MOUNTING AS-VIBRATION ISOLATOR
	I	CA0597	00	001	ELECT. MODULAR CONT. PANEL II+
<a href="#">NPR</a>	IY	<a href="#">141-2858</a>	01	001	CONTROL AR-EMCP ELECTRONIC
<a href="#">NPR</a>	IY	<a href="#">145-5219</a>	01	001	CONTROL GP-ENG RATINGS ELEK
	I	0P-8910		001	POST SALE SPAR
	I	PP2201	00	001	1180 BHP 836 GEN KW WOF 60 HZ
	I	2T-5777	00	001	880 KW @ 1800 RPM (1180 BHP)

Key: