

3406C GEN SET ENGINE

Engine Serial Number - 4ZR07048 (Build Date - 02/11/2000, Test Date - 03/11/2000, Ship Date - 15/11/2000)

[View Latest Kit Information](#)

ENGINE - ENTIRE GROUP (4ZR07048)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00350	F	001	350 EKW W/FAN
		I	406DE38	F	001	3406 208 VOLT 60 HZ PGS
		I	OGNPM04	F	001	GENERATOR 449 FRAME PM
		I	RPA0004	F	001	GENERATOR REMOVAL
		I	GOVEL01	F	001	1724 ELECTRONIC GOVERNOR
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCLH01	F	001	LH MTG OF CONTROL PANEL
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	EMCCIM1	F	001	CUSTOMER INTERFACE MODULE-CIM
		I	RRMC001	F	001	RADIATOR REMOVAL
		I	NSB0001	F	001	NARROW BASE
		I	EXCFF05	F	001	FLEXIBLE FITTING - ANSI FLANGE
		I	RCP0801	F	001	RAIN CAP
		I	BTRCBL1	F	001	BATTERY CABLES
		I	BTR0001	F	001	BATTERY RACK
		I	JWH0001	F	001	JACKET WATER HEATER
		I	PFF0002	F	001	PRIMARY FUEL FILTER
		I	FWS0001	F	001	WATER SEPARATOR
		I	CBK3P17	F	001	1200AMP 3 POLE CIRCUIT BREAKER
		I	CBS3P02	F	001	AUXILIARY SWITCH
		I	MUFCR02	F	001	MUFFLER - CRITICAL (M41)
		I	60H-0208	F	001	60HZ 208 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG
		I	STANDBY	F	001	STANDBY POWER APPLICATION 02

	I	CBKLH01	F	001	LH MOUNT CIRCUIT BREAKER	
	I	NONCERT	F	001	NOT EPA&CARB NONROAD EMIS CERT	
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL	
					PART NUMBERS	
	I	PP3420	01	001	519 BHP 362 GEN KW WOF 60 HZ S	
	I	0P-9174		001	0P9174 PWR PRICING PGM769-00	
	I	0P-9190		001	0P1910 PWR PRICING PGM769-00	
	NPR	IY 111-3794	01	001	SENSOR GP-COOLANT LEVEL	
	I	CA0339	04	001	3406 208 VOLT 60 HZ PGS	
	NPR	IY 128-7027	04	001	ENGINE AR	
	NPR	IY 2W-8198	09	001	SHUTOFF GP-ELECTRICAL	
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II	
	NPR	IY 4N-1062	09	001	STARTING MOTOR GP-ELECTRIC	
	NPR	IY 4P-7610	03	001	SENSOR GP-SPEED	
	NPR	IY 4W-1727	00	001	COVER GP-FUEL TRANSFER	
	I	5N-7601		001	NOTE-CONTROL & POWER PANEL	
	I	5P-2506	00	001	LITERATURE GP	
	NPR	I	5P-2586	03	001	OIL
	NPR	IY 6L-2927	08	001	ELBOW GP-EXHAUST	
	NPR	IY 8N-6115	03	001	AIR CLEANER GP	
	NPR	IY 103-1736	01	001	WIRING GP-PANEL	
	NPR	IY 103-1956	00	001	MOUNTING GP-CONTACTOR	
	NPR	IY 103-6101	04	001	CONTROL GP-ENGINE MONITORING	
	NPR	IY 104-4704	03	001	MOUNTING GP-CONTROL PANEL	
	NPR	IY 109-3319	03	001	COUPLING GP-GENERATOR	
	NPR	IY 129-6803	03	001	CONNECTION GP-ELECTRICAL	
	NPR	IY 129-7504	02	001	LINES GP-ENGINE OIL DRAIN	
	NPR	IY 130-3480	02	001	MOUNTING GP-VOLTAGE REGULATOR	
	I	3L-0284		001	*****TEST - PKG GEN SET*****	
	I	CA0382	00	001	GENERATOR 449 FRAME PM	
	NPR	IY 130-3649	01	001	REGULATOR GP-VOLTAGE	
	NPR	IY 130-4711	01	001	GENERATOR AR	
	I	CA0398	00	001	GENERATOR REMOVAL	
	I	PA5018	03	001	1724 ELECTRONIC GOVERNOR	
	NPR	IY 7E-0123	00	001	MOUNTING GP-GOVERNOR ACTUATOR	
	NPR	IY 7E-0598	00	001	ACTUATOR AS-GOVERNOR	

	NPR	IY	131-5455	02	001	CONTROL AS-GOVERNOR
		I	121-4713	00	001	INSTRUCTIONS
		I	CA0445	00	001	LH MTG OF CONTROL PANEL
		I	5N-7575		001	NOTE-CONTROL PANEL MTG. LH.
	NPR	IY	121-4716	01	001	MODULE GP-ALARM
	NPR	IY	121-4712	01	001	PANEL GP-ELECTRONIC
	NPR	IY	9Y-6496	02	001	MODULE GP-INTERFACE
		I	CA0509	04	001	RADIATOR REMOVAL
	NPR	IY	2W-7257	06	001	GUARD GP-DAMPER
		I	CA0461	01	001	NARROW BASE
	NPR	IY	107-6332	01	001	BASE GP-ENGINE & GENERATOR
	NPR	IY	136-5937	01	001	FITTING GP-EXHAUST
	NPR	I	125-5700	01	001	CAP AS-RAIN
	NPR	IY	7W-0825	01	001	CABLE GP-BATTERY
	NPR	IY	3N-7056	00	001	SUPPORT GP-BATTERY
		I	CA0470	01	001	JACKET WATER HEATER
	NPR	IY	7E-6247	03	001	HEATER GP-JACKET WATER
	NPR	IY	129-4439	03	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	147-3081	02	001	FILTER GP-FUEL
	NPR	IY	116-1920	00	001	SEPARATOR GP-WATER
		I	CA0419	03	001	CIRCUIT BREAKER W/ST 1200 AMP
	NPR	IY	105-7185	01	001	HARNESS AS-PANEL
	NPR	IY	111-9709	00	001	CIRCUIT BREAKER GP
	NPR	IY	129-5841	00	001	COVER GP-GENERATOR
	NPR	IY	130-1968	02	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	IY	130-2572	00	001	BOX GP-EXTENSION TERMINAL
	NPR	IY	6I-3339	00	001	NEUTRAL BUS BAR AS
	NPR	IY	130-2569	00	001	FASTENER GP-EXTENSION BOX
	NPR	IY	105-7931	01	001	SWITCH AS-AUXILIARY
	NPR	IY	115-1360	00	001	MUFFLER
		I	5N-9593		001	VOLTAGE INDICATOR - 208 VOLT
		I	0V-1065		001	END USE: GENERAL EPG
		I	9Y-8156		001	STANDBY POWER APPLICATION
		I	5N-7596		001	NOTE - MOUNT CIRCUIT BKR LH
		I	PP3420	01	001	519 BHP 362 GEN KW WOF 60 HZ S
		I	2T-8200	00	001	387 KW @ 1800 RPM (519 BHP)

		I	5N-7545		001	NOTE-REMOVE STD GOV SPRING
	NPR	I	7N-1295	01	001	SPRING SHIPPED LOOSE
	NPR	S	3K-1715		001	CABLE AS
	NPR	S	3N-7054		001	SUPPORT AS-BATTERY
	NPR	S	3N-7055		001	BOARD
	NPR	S	3V-6785		001	CABLE AS
	NPR	S	4K-0367		004	NUT-FULL
	NPR	S	5H-8331		001	GASKET
	NPR	S	5P-8247		008	WASHER-HARD
	NPR	S	6V-2687		002	SCREW-PAN HEAD
	NPR	S	7N-5274		001	COVER AS-TERMINAL
	NPR	S	8N-0869		001	COVER-TERMINAL
	NPR	S	8N-1725		001	COVER AS-TERMINAL
	NPR	S	9G-8909		001	COVER-TERMINAL
	NPR	SY	9X-0203		001	MODULE GP-RELAY DRIVER
	NPR	S	9X-8880		004	BOLT
	NPR	S	9Y-6497		001	BOARD AS-RELAY
		S	REHS0753		001	WARR. REGISTRATION 140010D2(A)
		S	SEBP2534		001	PT BK(EMCP 11) 140015B1(A)
		S	SEBP2547		001	PTSBK FL CC06E(A)
		S	SEBU6042		001	SUPP
		S	SEBU6251		001	LUBE RECOMMENDATION 1632-16(A)
		S	SEBU6918		001	OMM
		S	SEBU6999		001	OMM 16904-11(A)
		S	SELF5308		001	WARRANTY
		S	SENR4794		001	SCHEMATIC
		S	SMBU6981		001	SUPP 140015C2(A)
	NPR	SY	111-3794		001	SENSOR GP-COOLANT LEVEL
	NPR	SY	115-1360		001	MUFFLER
	NPR	S	125-5700		001	CAP AS-RAIN
	NPR	SY	130-7202		001	ADAPTER AS-EXHAUS