

Sales Model: 3516

Build Date: 2005

[Feature Code](#)[Part Numbers](#)[Ship Loose](#)[Help](#)**Feature Codes [Top](#)**

28 results found, displaying 1 to 28

| Reference Number | Eng Chg | Quantity | ASM LESS | Set Type | Description |
|------------------|---------|----------|----------|----------|--------------------------------|
| 516GE18 | F | 1 | I | | G3516B 60 HZ PGS-CONT 54C |
| OGNPM5T | F | 1 | I | | GEN 824 FRAME PM 12 |
| EMCENGU | F | 1 | I | | ENGLISH DISPLAY UNITS |
| CSA0001 | F | 1 | I | | CSA CERTIFICATION 03 |
| LSMOD03 | F | 1 | I | | GOV - LOAD SHARE MOD 03 |
| RPA0048 | F | 1 | I | | 697 FRAME GENERATOR REMOVAL 01 |
| MVC0003 | F | 1 | I | | MANUAL VOLTAGE CONTROL 02 |
| LVEXB02 | F | 1 | I | | LOW VOLTAGE EXTENSION BOX 02 |
| SHAFT01 | F | 1 | I | | FRONT STUB SHAFT |
| JWH0025 | F | 1 | I | | JACKET WATER HEATER 16 |
| SRP0014 | F | 1 | I | | PRESERVATION GP ENGINE -3516 |
| EXCFE02 | F | 1 | I | | FLANGE AND EXHAUST EXPANDER 02 |
| EXRVAL1 | F | 1 | I | | EXPLOSION RELIEF VALVE |
| BARGP01 | F | 1 | I | | ENGINE BARRING GROUP |
| CBK0037 | F | 1 | I | | CIR BKR W/ST 3 POLE 2000 A 05 |
| 60H0480 | F | 1 | I | | 60HZ 480 VOLTS |
| CONTINU | F | 1 | I | | CONTINUOUS APPLICATION |
| MSEPGGN | F | 1 | I | | GENERAL EPG |
| SWP0001 | F | 1 | I | | SHRINK WRAP PROTECTION - 3516 |
| TRSGEN2 | F | 1 | I | | PGS TEST REPORT @ 1.0 PF |
| PSD07 | F | 1 | I | | ENGINE DISTR DISCOUNT PRGM |
| MSCEC81 | F | 1 | I | | MINING |
| MWCODEF | F | 1 | I | | STANDBY POWER |
| KW01300 | F | 1 | I | | 1300 EKW W/O FAN |
| LANENGO | F | 1 | I | | ENGLISH LANGUAGE OPTION |
| ACTEMPB | F | 1 | I | | 99C/54C TWO STAGE |
| EMISS12 | F | 1 | I | | 1.0 G/BHP-HR NOX |
| PIPEGAS | F | 1 | I | | PIPELINE NATURAL GAS FUEL |

Part Numbers [Top](#)

90 results found, displaying 1 to 90

| Reference Number | Eng Chg | Quantity | ASM LESS | Set Type | Description | BreakDown... |
|------------------|---------|----------|----------|----------|--------------------------------|------------------------------|
| LA4235 | 02 | 1 | I | | G3516B 60HZ PKG GENSET W/ PUMP | BreakDown... |
| 2603659 | 02 | 1 | I | | ENGINE ARR - G3516B | BreakDown... |
| 3L0414 | | 1 | I | | SINGLE BEARING GEN ALIGN-3500 | BreakDown... |
| 3L0456 | | 1 | I | | PROCEDURE - DVR PROG AND TEST | BreakDown... |

| | | | | | |
|---------|----|---|---|--------------------------------|------------------------------|
| 3L0462 | | 1 | I | TEST- GAS GENSET | BreakDown... |
| 3N7056 | 00 | 1 | I | BATTERY RACK | BreakDown... |
| 5N8877 | 06 | 1 | I | VIBRATION ISOLATORS | BreakDown... |
| 5P2506 | 00 | 1 | I | LITERATURE - ENGLISH | BreakDown... |
| 7C0527 | 04 | 1 | I | ELECTRIC STARTING MOTOR LH | BreakDown... |
| 7E4836 | 08 | 1 | I | MOUNTING GP - ALT | BreakDown... |
| 7L7871 | 09 | 1 | I | 24 VOLT BATTERY SET - DRY | BreakDown... |
| 7W0825 | 01 | 1 | I | BATTERY CABLES | BreakDown... |
| 7W1678 | 02 | 1 | I | INDICATOR GP-FILTER CHANGE | BreakDown... |
| 7W5780 | 04 | 1 | I | GUARD GROUP - BELT | BreakDown... |
| 7X2425 | 02 | 1 | I | OIL-BULK-1 LITER: DO NOT DRAIN | BreakDown... |
| 8N9639 | 04 | 1 | I | GUARD GP-DAMPER | BreakDown... |
| 1077361 | 02 | 1 | I | DRIVE GP - ACC. | BreakDown... |
| 1085555 | 04 | 1 | I | SWITCH GP-DISCONNECT | BreakDown... |
| 1123455 | 00 | 1 | I | ALTERNATOR GP-CHARGING 24V-60A | BreakDown... |
| 1216202 | 09 | 1 | I | REGULATOR GP | BreakDown... |
| 1218855 | 06 | 1 | I | CONNECTION GP | BreakDown... |
| 1259749 | 04 | 1 | I | DAMPER GP | BreakDown... |
| 1530191 | 06 | 1 | I | INSTALLATION AR-GENERATOR | BreakDown... |
| 1664155 | 02 | 1 | I | WIRING GROUP - ELECTRIC START | BreakDown... |
| 1682029 | 00 | 1 | I | WIRING GP | BreakDown... |
| 1889078 | 03 | 1 | I | AIR CLEANER GP | BreakDown... |
| 1981905 | 00 | 1 | I | PAINT - FINISH | BreakDown... |
| 2010549 | 03 | 1 | I | DRAIN GP - OIL PAN | BreakDown... |
| 2057860 | 07 | 1 | I | MOUNTING GP - 17 DIGIT PIN | BreakDown... |
| 2120215 | 02 | 1 | I | CONTROL GROUP | BreakDown... |
| 1134174 | 05 | 1 | I | ELECTRIC PRELUBE PUMP (60 HZ) | BreakDown... |
| 1744107 | 01 | 1 | I | LINES GP - PRELUBE | BreakDown... |
| 2128947 | 00 | 1 | I | CONVERSION GROUP-D | BreakDown... |
| 9Y6992 | 05 | 1 | I | VALVE GP | BreakDown... |
| 1583531 | 00 | 1 | I | HARNESS ASSEMBLY | BreakDown... |
| 2199756 | 01 | 1 | I | WIRING GP | BreakDown... |
| 2231604 | 02 | 1 | I | FILM GROUP | BreakDown... |
| 2210752 | 00 | 1 | I | SPACE HEATER RELAY | BreakDown... |
| 1519228 | 02 | 1 | I | GUARD GROUP-ALTERNATOR | BreakDown... |
| 5N7562 | 00 | 1 | I | NOTE-CONTROL PANEL MTG (REAR) | BreakDown... |
| 1044704 | 03 | 1 | I | MTG GP - CONTROL PNL (EMCP II) | BreakDown... |
| 2028640 | 06 | 1 | I | DRAIN GP - OIL | BreakDown... |
| 2295706 | 04 | 1 | I | SENSOR GP-ENGINE | BreakDown... |
| 2413378 | 02 | 1 | I | WIRING GP (CBDVR +EMCP II) | BreakDown... |
| 2406833 | 01 | 1 | I | HARNESS AS (EMCP II LOW VOLTAG | BreakDown... |
| 2087482 | 00 | 1 | I | TEST - GEN ELE SYS LE | BreakDown... |
| 1219640 | 05 | 1 | I | CONNECTION GP - INTERCONNECT | BreakDown... |
| 2643746 | 00 | 1 | I | LINES GP-AIR | BreakDown... |
| LE0659 | 02 | 1 | I | GENERATOR ARR-SR4B-824 | BreakDown... |
| 1411809 | 03 | 1 | I | BOX GP-BASIC | BreakDown... |
| 1441820 | 03 | 1 | I | GENERATOR AR - POWER (A749) | BreakDown... |
| 1531030 | 05 | 1 | I | RAIL GP-ENG,GEN, RAD, & FLARED | BreakDown... |

| | | | | | |
|---------|----|---|---|--------------------------------|------------------------------|
| 1543477 | 02 | 1 | I | TRANSFORMER GP | BreakDown... |
| 1449060 | 02 | 1 | I | TRANSFORMER-CURRENT | BreakDown... |
| 1214713 | 00 | 1 | I | ENGLISH DISPLAY UNITS | BreakDown... |
| LE0317 | 01 | 1 | I | CSA CERTIFICATION | BreakDown... |
| 1214706 | 00 | 1 | I | CSA CERTIFICATION | BreakDown... |
| 2024869 | 00 | 1 | I | LOAD SHARING MODULE (CAT GOV) | BreakDown... |
| LE2218 | 03 | 1 | I | 697 FRAME GENERATOR REMOVAL FO | BreakDown... |
| LE0619 | 02 | 1 | I | MANUAL VOLTAGE CONTROL | BreakDown... |
| 5N0591 | 04 | 1 | I | MANUAL VOLTAGE CONTROL | BreakDown... |
| LE0608 | 00 | 1 | I | EXTENSION BOX - LOW VOLTAGE | BreakDown... |
| 1223487 | 03 | 1 | I | LOW VOLTAGE EXTENSION BOX | BreakDown... |
| LE2189 | 01 | 1 | I | FRONT STUB SHAFT | BreakDown... |
| 1507947 | 00 | 1 | I | FRONT STUB SHAFT | BreakDown... |
| LE2232 | 00 | 1 | I | JACKET WATER HEATER 16 | BreakDown... |
| 1765726 | 06 | 1 | I | MTG GP JW HEATER | BreakDown... |
| 1896642 | 02 | 1 | I | JACKET WATER HEATER | BreakDown... |
| LE2137 | 00 | 1 | I | STORAGE PRESERVATION WITH | BreakDown... |
| 1453211 | 03 | 1 | I | PRESERVATION GP ENGINE - 3516 | BreakDown... |
| PA0939 | 13 | 1 | I | FLANGE AND EXHAUST EXPANDER | BreakDown... |
| 7N6967 | 05 | 1 | I | FITTING GP - EXHAUST | BreakDown... |
| 2W7871 | 03 | 1 | I | FLANGE | BreakDown... |
| 8N8510 | 19 | 1 | I | EXPLOSION RELIEF VALVE | BreakDown... |
| 2532468 | 00 | 1 | I | ENGINE BARRING GROUP | BreakDown... |
| LE0336 | 04 | 1 | I | CIRCUIT BREAKER 2000A | BreakDown... |
| 1220330 | 03 | 1 | I | CONNECTION GP | BreakDown... |
| 2527537 | 03 | 1 | I | MOUNTING GP-BREAKER | BreakDown... |
| 2527535 | 01 | 1 | I | PANEL AS. | BreakDown... |
| 2527525 | 01 | 1 | I | MOUNTING GP-BRACKET | BreakDown... |
| 2617168 | 00 | 1 | I | WIRING GP | BreakDown... |
| 2527520 | 02 | 1 | I | PLATE | BreakDown... |
| 5N9597 | | 1 | I | 60HZ 480 VOLTS | BreakDown... |
| 9Y8164 | | 1 | I | CONTINUOUS APPLICATION | BreakDown... |
| 0V1065 | | 1 | I | END USE: GENERAL EPG | BreakDown... |
| 0P7607 | | 1 | I | SHRINK WRAP PROTECTION - 3516 | BreakDown... |
| 0P1910 | | 1 | I | STD. GEN SET TEST CHARGE | BreakDown... |
| LL0540 | 00 | 1 | I | 1818 BHP 1300 GEN KW WOF 60 HZ | BreakDown... |
| 0K6469 | | 1 | I | 1356 BKW (1818 BHP) @ 1800 RPM | BreakDown... |
| CA0866 | 07 | 1 | I | ENGLISH LANGUAGE OPTION | BreakDown... |

Ship Loose [Top](#)

56 results found, displaying 1 to 56

| Reference Number | Eng Chg | Quantity | ASM LESS | Set Type | Description | BreakDown... |
|------------------|---------|----------|----------|----------|------------------|------------------------------|
| ESO | | 1 | S | | (PRNT ESO COPY) | BreakDown... |
| PML | | 1 | S | | *REQUIRED DECALS | BreakDown... |
| 0S1571 | | 12 | S | | BOLT | BreakDown... |
| 0S1591 | | 8 | S | | BOLT | BreakDown... |
| 1B5355 | | 12 | S | | NUT-FULL | BreakDown... |
| 1B5357 | | 12 | S | | NUT-FULL | BreakDown... |

| | | | | |
|----------|----|---|------------------|------------------------------|
| 2B0858 | 1 | S | PLUG-PIPE | BreakDown... |
| 2V7397 | 2 | S | CABLE AS | BreakDown... |
| 2W7871 | 1 | S | FLANGE GP-EXH | BreakDown... |
| 2W7872 | 1 | S | FLANGE-EXHAUST | BreakDown... |
| 2W7873 | 1 | S | GASKET-EXHAUST | BreakDown... |
| 3K1715 | 2 | S | CABLE AS | BreakDown... |
| 3N7054 | 2 | S | SUPPORT AS-BAT | BreakDown... |
| 3N7055 | 2 | S | BOARD | BreakDown... |
| 3N7056 | 1 | S | SUPPORT GP-BAT | BreakDown... |
| 3V3308 | 8 | S | WASHER-HARD | BreakDown... |
| 3V6785 | 2 | S | CABLE AS | BreakDown... |
| 4P9477 | 1 | S | GASKET | BreakDown... |
| 5L3773 | 1 | S | GASKET-EXH ELBOW | BreakDown... |
| 5L4398 | 12 | S | BOLT | BreakDown... |
| 5N0591 | 1 | S | CONT GP -B | BreakDown... |
| 5N8877 | 1 | S | MTG GP-ENG FLEX | BreakDown... |
| 5P7197 | 8 | S | WASHER-HARD | BreakDown... |
| 5P8245 | 24 | S | WASHER-HARD | BreakDown... |
| 6L4502 | 1 | S | PROD MARKING SYS | BreakDown... |
| 7L7871 | 1 | S | BATTERY GP -B | BreakDown... |
| 7N5274 | 2 | S | COVER-TERMINAL | BreakDown... |
| 7N6959 | 1 | S | ADAPTER | BreakDown... |
| 7N6967 | 1 | S | FITTING GP-EXH | BreakDown... |
| 7W0825 | 1 | S | CABLE GP | BreakDown... |
| 8L8413 | 4 | S | STRAP-CABLE | BreakDown... |
| 8N0869 | 2 | S | COVER-TERMINAL | BreakDown... |
| 8N1725 | 2 | S | COVER-TERMINAL | BreakDown... |
| 9G0003 | 4 | S | COVER-TERMINAL | BreakDown... |
| 9G0004 | 4 | S | COVER-TERMINAL | BreakDown... |
| 9G8909 | 2 | S | COVER-TERMINAL | BreakDown... |
| 9L9132 | 24 | S | WASHER-HARD | BreakDown... |
| 9S8752 | 8 | S | NUT-FULL | BreakDown... |
| 9X3406 | 1 | S | RECEPTACLE AS | BreakDown... |
| 9X8917 | 4 | S | SCREW-MACHINE | BreakDown... |
| 9X9720 | 4 | S | BATTERY-12 VOLT | BreakDown... |
| 9Y6992 | 1 | S | VALVE GP-SOL | BreakDown... |
| 9Y6993 | 1 | S | ADAPTER | BreakDown... |
| 1030692 | 1 | S | VALVE GP-SOL | BreakDown... |
| 1218855 | 1 | S | CONNECTION GP -G | BreakDown... |
| 1441820 | 1 | S | GENERATOR AR-PWR | BreakDown... |
| 1533864 | 8 | S | MOUNT AS | BreakDown... |
| 1583531 | 1 | S | HARNESS AS-WRG | BreakDown... |
| 1716719 | 1 | S | PARTS KIT | BreakDown... |
| 1716721 | 1 | S | PARTS KIT | BreakDown... |
| 2024869 | 1 | S | CONTROL AS-GOV | BreakDown... |
| REHS0531 | 1 | S | SI | BreakDown... |
| SEBU6400 | 1 | S | LUBE | BreakDown... |
| SEBU7566 | 1 | S | OMM | BreakDown... |
| SELF5397 | 1 | S | WARRANTY | BreakDown... |
| SERP3863 | 1 | S | PTSCD | BreakDown... |