

Engine Serial Number - 1HZ01192 (Build Date - 27/06/2001, Test Date - 01/07/2001, Ship Date - 19/07/2001)

[View Latest Kit Information](#)

ENGINE - ENTIRE GROUP (1HZ01192)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
<input type="checkbox"/>		I	KW01825	F	001	1825 EKW W/FAN
<input type="checkbox"/>	NPR	IY	205-6513	F	001	HARNESS AS-ENGINE
<input type="checkbox"/>		I	516DE16	F	001	3516B POWER MODULE
<input type="checkbox"/>		I	PRIPLUS	F	001	PRIME PLUS 10% POWER APPL.
<input type="checkbox"/>		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS 01
<input type="checkbox"/>		I	ELEDUPR	F	001	DUPLEX RECEPTACLE - 120 VAC
<input type="checkbox"/>		I	ELEBLCA	F	001	BOTTOM LOAD CABLE ACCESS
<input type="checkbox"/>		I	FULTRS5	F	001	1250 GAL DW FUEL TRANSFER SYS
<input type="checkbox"/>		I	FULEXFF	F	001	EXTERIOR FUEL FILL
<input type="checkbox"/>		I	LUBOMU3	F	001	LUBE OIL MAKE-UP SYSTEM
<input type="checkbox"/>		I	SGRUGS2	F	001	UTILITY GRADE SWITCHGEAR
<input type="checkbox"/>		I	DECRPOW	F	001	RENTAL POWER DECAL
<input type="checkbox"/>		I	MNT403A	F	001	UNDERCARRIAGE AR.-40 FT-3 AXLE
<input type="checkbox"/>		I	CERTIFD	F	001	EPA & CARB NON-ROAD EMIS. CERT
<input type="checkbox"/>		I	60H-0480	F	001	60HZ 480 VOLTS
<input type="checkbox"/>		I	MSEPGGN	F	001	GENERAL EPG
<input type="checkbox"/>		I	SOUNDAT	F	001	SOUND ATTENUATED
<input type="checkbox"/>		I	XQRENTL	F	001	XQ RENTAL POWER
						PART NUMBERS
<input type="checkbox"/>		I	GG0001	01	001	2628 BHP 1825 GEN KW W/F 60 HZ
<input type="checkbox"/>		I	0P-8707		001	QUOTE NO.-
<input type="checkbox"/>		I	204-4118	00	001	INSTRUCTIONS - SWGR
<input type="checkbox"/>		I	194-1581	00	001	RELAY GP - POWER
<input type="checkbox"/>		I	193-4621	02	001	PANEL AR
<input type="checkbox"/>	NPR	I	183-8051	04	001	PANEL GP-ELECTRONIC

	I	183-8050	01	001	PANEL GP-CONTROL
	I	204-1134	00	001	PANEL AR-AUX
	IY	197-7161	01	001	PANEL AR-SWITCHGEAR
	NPR	ILY 151-5673	01	001	CONNECTION GP-ELECTRICAL
	NPR	IY 202-7903	01	001	CONDUIT GP-ELECTRICAL
	I	209-6242	00	020	HARNESS ASSY
	I	LA3460	06	001	3516B POWER MODULE.
	IY	188-7945	00	001	GENERAL AR
	I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
	NPR	IY 3N-4905	03	001	HOSE AS
	NPR	IY 4P-7072	01	001	CONNECTION GP-WATER
	NPR	I 5N-2438	05	001	LINES GP-FLEXIBLE FUEL
	I	5N-9955		001	JWH CONN IND - 120V, 60HZ
	I	5P-2506	00	001	LITERATURE GP
	NPR	I 5P-2586	03	001	OIL
	NPR	IY 7C-0527	02	001	STARTING MOTOR GP-ELECTRIC
	NPR	IY 7E-2858	00	001	ALTERNATOR GP-CHARGING
	NPR	IY 7E-4836	05	001	MOUNTING GP-ALTERNATOR
	NPR	IY 7E-6247	03	001	HEATER GP-JACKET WATER
	NPR	IY 7N-6782	07	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	IY 7W-5780	04	001	GUARD GP-BELT
	NPR	IY 7W-9704	06	001	PUMP GP-SUMP
	NPR	IY 8N-9639	04	001	GUARD GP-DAMPER
	NPR	IY 107-7361	00	001	DRIVE GP-ACCESSORY
	NPR	IY 113-1581	00	001	AIR CLEANER GP
	NPR	IY 115-1065	02	001	PUMP GP-FUEL PRIMING
	NPR	IY 115-3613	04	001	MOUNTING GP-AIR CLEANER
	NPR	IY 115-7841	14	001	FILTER GP-ENGINE OIL
	NPR	IY 115-7842	05	001	FILTER GP-FUEL
	NPR	IY 116-7004	02	001	REGULATOR GP-TEMPERATURE
	NPR	IY 121-8856	07	001	CONNECTION GP-ELECTRICAL
	NPR	IY 125-9326	01	001	TRANSFORMER GP-POTENTIAL
	NPR	IY 129-4337	06	001	CONTROL GP-EMCP ELECTRONIC
	NPR	IY 130-5653	03	001	PANEL GP-CONTROL
	NPR	IY 131-2837	03	001	PANEL GP-CONTROL
	NPR	IY 131-2960	02	001	RELAY GP

	NPR	IY	134-0061	05	001	WIRING GP-ENGINE
	NPR	IY	134-3159	05	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	134-3160	05	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	135-3319	03	001	BATTERY CHARGER GP
	NPR	IY	136-2054	02	001	MODULE GP-ALARM
	NPR	IY	140-2665	01	001	FUMES DISPOSAL GP
	NPR	IY	141-1598	01	001	SWITCH GP-DISCONNECT
	NPR	IY	141-1809	03	001	BOX GP-GENERATOR CONNECTION
	NPR	IY	141-6413	00	001	RAIL GP-SLIDE
	NPR	IY	144-1952	01	001	GENERATOR AR
	NPR	IY	145-2911	06	001	BOX GP-CONTROL PANEL
	NPR	IY	147-1165	10	001	SWITCHGEAR AR
	NPR	IY	149-2477	00	001	SUPPORT AS
	NPR	IY	149-8779	02	001	HEATER GP-SPACE
	NPR	IY	151-9265	01	001	HARNESS AS-SENSOR
	NPR	IY	151-9266	03	001	HARNESS AS-SENSOR
	NPR	IY	153-0191	05	001	INSTALLATION AR-GENERATOR
	NPR	IY	153-7726	03	001	CONTROL GP-LOAD SHARE MODULE
	NPR	IY	155-1390	01	001	MOUNTING GP-ENGINE
	NPR	IY	155-1701	01	001	MOUNTING GP-POWER MODULE
	NPR	IY	161-2491	01	001	RAIL GP-ENGINE SUPPORT
	NPR	IY	170-6481	00	001	PANEL GP-CONTROL
	NPR	IY	178-9030	01	001	BOX AS-STORAGE
		I	179-2318	00	001	HARNESS AS
		I	179-7264	00	001	PACKAGING ARRANGEMENT
	NPR	IY	183-1201	03	001	MUFFLER GP
	NPR	IY	192-0788	01	001	DRAIN GP-COOLANT
	NPR	IY	197-3887	01	001	MOUNTING GP-ENGINE OIL FILTER
	NPR	IY	202-8640	01	001	DRAIN GP-ENGINE OIL
	NPR	I	119-5148	01	001	COOLANT-EXTENDED LIFE
	NPR	IY	192-4902	02	001	PANEL GP-SOUND SUPPRESSION
	NPR	IY	163-1462	00	001	SENSOR & MTG GP-ELECTRIC
		I	198-1905	00	001	PAINT
	NPR	IY	188-1765	02	001	CONTAINER AR
		I	188-3222	00	001	LINES GP-WATER
	NPR	IY	189-6425	01	001	LOUVER GP

	NPR	I	202-0836	00	001	PANEL GP-ENCLOSURE
	NPR	IY	205-7860	00	001	FILM GP
	NPR	IRY	188-9442	02	001	ENGINE AR
	NPR	IY	202-1295	00	001	LOUVER GP
	NPR	IY	189-9100	03	001	MOUNTING GP-RADIATOR
	NPR	IY	190-0376	02	001	LINES GP-VENT
	NPR	IY	208-6899	00	001	RADIATOR GP
	NPR	IY	190-1328	01	001	BAFFLE GP-RADIATOR
	NPR	I	190-2280	01	001	SUPPORT GP-WATER LINES
		I	9Y-8163		001	PRIME + 10% POWER APPLICATION
		I	121-4713	00	001	INSTRUCTIONS
		I	LA3485	00	001	DUPLEX RECEPTACLE - 120V
	NPR	IY	102-6843	02	001	BOX GP-TERMINAL
		I	LA3486	00	001	BOTTOM LOAD CABLE ACCESS
	NPR	IY	113-1217	00	001	DOOR AS
		I	LE2000	03	001	DOUBLE WALL 1250 GALLON FUEL T
	NPR	IY	146-9839	08	001	PANEL GP-CONTROL
	NPR	IY	191-2411	00	001	TANK GP-FUEL
		I	LA3493	00	001	EXTERIOR FUEL FILL
	NPR	IY	164-4580	02	001	DOOR AS
		I	LA3468	00	001	LUBE OIL MAKEUP SYSTEM
	NPR	IY	5N-4659	07	001	REGULATOR GP-OIL LEVEL
	NPR	IY	102-6845	03	001	TANK GP-ENGINE OIL
		I	102-6848	00	001	ALARM GP-LOW OIL LEVEL
		I	LA3535	06	001	3000A, 480V UTILITY GRADE UPGR
	NPR	IY	121-6203	06	001	REGULATOR GP-VOLTAGE
	NPR	IY	125-9976	00	001	RELAY GP
	NPR	IY	129-3164	03	001	ENCLOSURE GP-EXTENSION
	NPR	IY	131-0341	01	001	METER GP-POWER FACTOR
	NPR	IY	136-4703	00	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	IY	136-6168	02	001	PANEL AR-UTILITY
	NPR	IY	147-1186	01	001	CONTROL GP-CIRCUIT BREAKER
	NPR	IY	147-1190	01	001	PARALLELING GP-AUTOMATIC
	NPR	IY	149-8781	02	001	HEATER GP-SPACE
		I	172-5645	08	001	PANEL GP
		I	190-6718	00	001	GANEL GP (VPAP)

	I	196-7263	01	001	DIMENSIONS-GENERAL
	I	196-7266	02	001	INSTRUCTIONS
	NPR	IY 178-6325	01	001	MOUNTING GP-VIBRATION ISOLATOR
	NPR	IY 206-7055	02	001	CONNECTION GP-GENERATOR LEADS
	NPR	IY 206-1236	01	001	BATTERY GP
	I	209-6242	00	001	HARNESS ASSY
	I	LA2977	01	001	RENTAL POWER DECALS
	I	142-2386	01	001	PLATE & FILM GP
	I	LA2990	04	001	UNDERCARRIAGE AR-40 FT-3 AXLE
	I	9Y-1385	01	001	UNDERCARRIAGE AR
	NPR	IY 9Y-1392	02	001	JACK
	NPR	IY 151-5714	00	001	LADDER GP
	NPR	IY 156-9155	01	001	HANDLE AS
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	0V-1065		001	END USE: GENERAL EPG
	I	GG0001	01	001	2628 BHP 1825 GEN KW W/F 60 HZ
	I	5N-9635		001	CONVENIENCE NUM
	I	0K-2944		001	1960 BKW (2628 BHP) @ 1800 RPM