

Engine Serial Number - 3FZ02080 (Build Date - 19/12/2000, Test Date - 20/12/2000, Ship Date - 29/12/2000)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (3FZ02080)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00500	F	001	500 EKW W/FAN
		I	412DE1J	F	001	3412 480/277V 60 HZ
		I	ENCWP14	F	001	WEATHER PROT ENCL-IND - YELLOW
		I	FTBDW34	F	001	SDW FUEL TNK BS-1000GAL(3785L)
		I	FUMDIS1	F	001	FUMES DISPOSAL
		I	EXTEN01	F	001	EXTENSION
		I	EXTEN04	F	001	EXTENSION
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCCPRH	F	001	CONTROL PANEL MOUNTING - RH
		I	EMCCAS1	F	001	COMMON ALARM/SHUTDOWN
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	COLHTR2	F	001	JACKETWATER COOLANT HEATER
		I	AFTS101	F	001	AUTO FUEL TRANS SYS1 (AFTS1)
		I	BTC1014	F	001	BATTERY CHARGER-10AMP DUALRATE
		I	BAT2416	F	001	OVERSIZE BATTERY
		I	CNTCT01	F	001	CONTACTOR GP
		I	CBK0048	F	001	800AMP 3-POLE CIRCUIT BREAKER
		I	PTSREM1	F	001	REMOVAL AR-POWER TERM. STRIP
		I	CBRH002	F	001	CIRCUIT BREAKER - RH
		I	CBS3P02	F	001	AUXILIARY SWITCH
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG (NON-ENCLOSED)
		I	STANDBY	F	001	STANDBY POWER
		I	LANENGO	F	001	ENGLISH LANGUAGE OPTION
		I	NONCERT	F	001	NON-CERTIFIED

	I	2301GOV	F	001	2301 GOVERNOR	
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL	
	I	BOTCBLE	F	001	BOTTOM CABLE ENTRY CIRCUIT BKR	
					PART NUMBERS	
	I	PP4127	02	001	749 BHP 515 GEN KW WOF 60 HZ S	
	I	0P-9185		001	0P9185 PWR PRICING PGM769-00	
	I	0V-1317		001	01JAN01 PRC PROTECT PGM641-11	
	I	CA1277	05	001	ENGINE AR-BASIC 3412 DIT PKG G	
	NPR	IY	167-6899	00	001	GENERAL AR
	NPR	IY	166-8592	02	001	ENGINE AR
		I	3L-0284		001	*****TEST - PKG GEN SET*****
		I	3L-0303		001	ADJUSTING-WW 2301 CONTROL SYS
	NPR	IY	3N-8594	03	001	COVER GP-ENGINE LIFTING EYE
	NPR	I	5P-2506	00	001	LITERATURE GP
	NPR	IY	6N-8878	02	001	GAUGE GP-FUEL PRESSURE
	NPR	I	119-5148	01	001	COOLANT-EXTENDED LIFE
	NPR	IY	142-6947	04	001	SENSOR GP-COOLANT LEVEL
	NPR	IY	143-9518	05	001	REGULATOR GP-VOLTAGE
	NPR	IY	149-7876	03	001	FASTENER GP-GENERATOR COUPLING
	NPR	IY	149-7899	02	001	SENSOR GP-ENGINE
	NPR	IY	151-7733	04	001	SWITCH GP-DISCONNECT
	NPR	IY	153-3434	03	001	MOUNTING GP-ENGINE FLEXIBLE
	NPR	IY	155-6256	00	001	CONTROL GP-GOVERNOR
	NPR	IY	155-8892	03	001	DROOP KIT
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	NPR	IY	168-3241	05	001	ENCLOSURE GP-GENERATOR
	NPR	IY	168-3290	02	001	AIR CLEANER GP
	NPR	IY	169-0198	07	001	PANEL GP-ELECTRONIC
	NPR	IY	169-0226	03	001	BOX GP-JUNCTION
	NPR	IY	169-0247	05	001	BOX GP-EXTENSION TERMINAL
	NPR	IY	169-0296	02	001	CONNECTION GP-GENERATOR LEADS
	NPR	IY	169-2050	08	001	RADIATOR & FAN GP
	NPR	IY	169-4439	03	001	HARNESS AS-WIRING
	NPR	IY	169-4441	03	001	HARNESS AS-WIRING
	NPR	IY	169-4444	03	001	HARNESS AS-WIRING
	NPR	IY	169-4450	02	001	HARNESS AS-WIRING

	IY	173-7080	00	001	GENERATOR AR	
	NPR	IY	180-3986	02	001	MOUNTING GP-JUNCTION BOX
	NPR	IY	156-0040	00	001	TRANSFORMER GP-CURRENT
	NPR	IY	188-8214	01	001	GUARD GP-BELT
		I	CA1907	02	001	ENCLOSURE GP-GENERATOR
	NPR	IY	188-1003	02	001	ENCLOSURE GP-GENERATOR
		I	CA1891	02	001	BASE GP-FUEL TANK
	NPR	IY	168-3252	02	001	LINES GP-COOLANT DRAIN
	NPR	IY	169-2121	01	001	LINES GP-ENGINE OIL DRAIN
	NPR	IY	170-8402	02	001	BASE GP-ENGINE & GENERATOR
	NPR	IY	170-8426	01	001	LINES GP-FUEL
	NPR	IY	171-4503	02	001	TANK & BASE GP-FUEL
	NPR	IY	198-8793	00	001	SUPPORT GP-BATTERY
		I	CA1942	00	001	REMOVAL AR-DISPOSAL GP
	NPR	IY	169-2120	01	001	FUMES DISPOSAL GP
	NPR	IY	188-3851	03	001	EXTENSION GP-FUEL TANK
	NPR	IY	188-3854	01	001	EXTENSION GP-FUEL TANK
		I	CA0846	02	001	ENGLISH DISPLAY UNITS
		I	121-4713	00	001	INSTRUCTIONS
		I	CA1787	01	001	MOUNTING GP-CONT PANEL(RH)
	NPR	IY	169-2106	02	001	COVER GP-ACCESS
		I	CA1430	02	001	RELAY GP-COMMON ALARM/SHUTDOWN
	NPR	IY	171-6833	02	001	RELAY GP
	NPR	IY	190-2565	01	001	HARNES AS-WIRING
		I	CA1436	01	001	CONTROL GP-ALARM MODULE-NFPA99
	NPR	IY	171-6827	03	001	PANEL GP-INSTRUMENT
		I	CA1389	01	001	HEATER GP-JACKET WATER-6000 WA
	NPR	IY	168-3238	02	001	HEATER GP-JACKET WATER
	NPR	IY	171-6841	02	001	CONNECTION GP-ELECTRICAL
		I	CA1478	01	001	FUEL GP-AUTOMATIC TRANSFER SYS
	NPR	IY	171-4492	00	001	PUMP GP-FUEL TRANSFER
	NPR	IY	171-6835	02	001	CONNECTION GP-ELECTRICAL
		I	CA1946	01	001	BATTERY CHARGER - 10 AMP UL W/
	NPR	IY	114-6486	00	001	BATTERY CHARGER
	NPR	IY	171-6844	03	001	CONNECTION GP-ELECTRICAL
	NPR	IY	184-7040	01	001	MOUNTING GP-BATTERY CHARGER

	I	CA1073	01	001	OVERSIZE BATTERY
NPR	IY	7L-7872	08	001	BATTERY GP
NPR	IY	184-7031	00	001	CONTACTOR GP
	I	CA1993	01	001	BREAKER GP-CIRCUIT-800 AMP-UL
NPR	IY	169-0237	03	001	COVER GP-GENERATOR
NPR	IY	169-4524	04	001	MOUNTING GP-CIRCUIT BREAKER
NPR	IY	183-2489	01	001	CIRCUIT BREAKER GP
NPR	IY	184-7038	00	001	WIRING GP-PANEL
NPR	IY	189-8892	01	001	CONNECTION GP-GENERATOR LEADS
	I	CA1764	01	001	REMOVAL AR-1200 AMPS PTS
	I	CA1774	01	001	COVER GP-CIRCUIT BREAKER-RIGHT
	I	5N-9698		001	NOTE- SINGLE BREAKER RIGHT
NPR	IY	105-7931	01	001	SWITCH AS-AUXILIARY
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	0V-1065		001	END USE: GENERAL EPG
	I	9Y-8156		001	STANDBY POWER APPLICATION
	I	CA0866	02	001	LANGUAGE MARKINGS-ENGLISH
	I	PP4127	02	001	749 BHP 515 GEN KW WOF 60 HZ S
	I	2T-9804	00	001	558.5 KW @ 1800 RPM (749 BHP)