

3512 Gen Set Engine

Engine Serial Number - 24Z09201

Engine Build Date - 1999/07/16

Engine - Entire Group (24Z09201)

Part Number	Change Level	Part Name
<u>129-5801</u> I	00	Meter GP-Watt
<u>102-8405</u> I	01	Louver AS
<u>131-2960</u> I, L	02	Relay GP
<u>129-5798</u> I, L	00	Meter GP-Watt
<u>8N-9302</u> I, L	08	Air Cleaner GP
<u>2W-8405</u> I	27	Engine AR
<u>3N-4905</u> I	03	Hose AS
<u>4P-7610</u> I	02	Sensor GP-Speed
<u>4W-4753</u> I	02	Switch GP-Magnetic
<u>7C-0526</u> I	01	Starting Motor GP-Electric
<u>7E-2858</u> I	00	Alternator GP-Charging
<u>7E-4836</u> I	04	Mounting GP-Alternator
<u>7E-6247</u> I	02	Heater GP-Jacket Water
<u>7N-6782</u> I	08	Indicator GP-Air Filter Change
<u>7W-3953</u> I	08	Drive GP-Fan
<u>7W-5224</u> I	00	Pulley GP-Fan Drive
<u>7W-5639</u> I	02	Fan GP-Blower
<u>7W-5780</u> I	04	Guard GP-Belt
<u>7W-6669</u> I	01	Guard GP-Damper
<u>7W-7214</u> I	04	Guard GP-Belt
<u>7W-9032</u> I	04	Enclosure GP-Wiring
<u>7W-9465</u> I	04	Pump GP-Fuel Priming
<u>7W-9704</u> I	05	Pump GP-Sump
<u>8N-9639</u> I	04	Guard GP-Damper
<u>104-9727</u> I	04	Mounting GP-Contactor

Part Number	Change Level	Part Name
<u>105-2048</u> 	02	Sensor & Mtg GP-Radiator
<u>105-3255</u> 	00	Mounting GP-Circuit Breaker
<u>105-7183</u> 	02	Fastener GP-Wiring Harness
<u>112-7978</u> 	01	Muffler GP
<u>115-7033</u> 	00	Rail GP-Engine & Gen Support
<u>121-8855</u> 	06	Connection GP-Electrical
<u>125-9326</u> 	01	Transformer GP-Potential
<u>129-2237</u> 	01	Harness AS-Wiring
<u>130-5379</u> 	01	Paralleling GP-Manual
<u>130-5652</u> 	01	Panel GP-Control
<u>131-2837</u> 	03	Panel GP-Control
<u>131-7253</u> 	04	Control GP-Governor
<u>134-0958</u> 	06	Bus Bar GP
<u>134-3241</u> 	01	Sensor GP-Temp & Press
<u>135-3319</u> 	03	Battery Charger GP
<u>136-9369</u> 	03	Mounting GP-Jacket Wtr Heater
<u>136-9370</u> 	02	Mounting GP-Jacket Wtr Heater
<u>140-2665</u> 	00	Fumes Disposal GP
<u>141-1598</u> 	00	Switch GP-Disconnect
<u>141-4950</u> 	00	Rail GP-Slide
<u>141-7883</u> 	00	Box AS-Storage
<u>146-0806</u> 	01	Door AS-Access
<u>147-1165</u> 	08	Switchgear AR
<u>147-1168</u> 	00	Panel GP-Switchgear
<u>149-6401</u> 	00	Battery GP
<u>151-5673</u> 	01	Connection GP-Electrical
<u>152-2876</u> 	02	Harness AS-Wiring
<u>153-0180</u> 	00	Vent GP-Fuel Tank

Part Number	Change Level	Part Name
112-6629 I	02	Baffle GP
155-4428 I	02	Radiator GP
121-6202 I	06	Regulator GP-Voltage
145-5138 I	00	Wiring GP-Electronic Control
122-6588 I	00	Transformer AS-Current
130-5653 I	03	Panel GP-Control
149-8779 I	02	Heater GP-Space
7W-2035 I	02	Guard AS-Radiator
140-2674 I	00	Valve GP-Radiator Drain
152-8792 I	03	Insulation GP-Generator
168-8623 I	00	Container AR
102-6849 I	01	Lighting AR
131-5025 I	02	Lighting GP-Generator
141-7897 I	02	Tank GP-Fuel
146-9839 I	07	Panel GP-Control
9Y-1392 I	02	Jack
151-5714 I	00	Ladder GP
156-9155 I	01	Handle AS
162-8683 I	00	Mounting GP-Engine
113-1217 I	00	Door AS
102-6818 I	02	Fire Extinguisher GP
3E-3361 S		Plug AS-Connector
3E-3362 S		Wedge-Plug Lock
6I-2933 S		Indicator-Air Filter Service
8L-8413 S		Strap-Cable
8N-2555 S		Filter-Soot
8T-6761 S		Plug-Pipe
8T-8730 S		Socket-Connector

Part Number	Change Level	Part Name
<u>171-6719</u> S		Kit-Parts
<u>171-6721</u> S		Kit-Parts

I - Installed
L - Less Indicator
S - Shipped Loose