

 **SIS 2.0**

Engine - Generator Set > Gen Set Engine > 3412 > 2WJ02440 ☆

-  Dashboard
-  **Parts**
-  Service



> **Parts**

> **Alternate Parts**

∨ **Product Configuration** ⓘ

**3412 Gen Set Engine**

Machine Serial Number - 2WJ02440

Machine Build Date - 08/03/1999

**3412 Gen Set Engine**

Engine Serial Number - 2WJ02440

Engine Build Date - 08/03/1999

**Product - Entire Group (2WJ02440)**

Part Number	Serial Number	Part Name	Install Ind.	Install Date	Description
<a href="#">105-7185</a>		Harness AS-Panel	Factory	—	WIRING GP
<a href="#">108-1056</a>		Cover GP-Extension Box	Less	—	COVER GP
<a href="#">108-1060</a>		Cable GP-Generator Ground	Less	—	CABLE GP - POWER
<a href="#">108-1061</a>		Circuit Breaker GP	Less	—	UNKNOWN PART
<a href="#">111-3794</a>		Sensor GP-Coolant Level	Factory	—	SENSOR GP-COOLANT LEVEL
111-9705		Circuit Breaker GP	Factory	—	UNKNOWN PART
<a href="#">121-4712</a>		Panel GP-Electronic	Factory	—	PANEL LIGHTS/AUXILIARY RELAY

Part Number	Serial Number	Part Name	Install Ind.	Install Date	Description
121-4713		Instructions	Factory	—	ENGLISH DISPLAY UNITS
<u>121-4716</u>		Module GP-Alarm	Factory	—	ALARM MODULE-8 LIGHT NFPA 99
<u>134-1157</u>		Relay GP	Factory	—	ENGINE FAILURE RELAY
<u>4P-4968</u>		Mounting GP-Circuit Breaker	Less	—	MOUNTING GP - CIRCUIT BREAKER
<u>7C-5296</u>		Panel GP-Instrument	Factory	—	REM 8-LIGHT NFPA99 STD BOX
<u>7E-4261</u>		Fumes Disposal GP	Factory	—	FUMES DISPOSAL
<u>7L-7872</u>		Battery GP	Factory	—	24V BAT SET-WET/1400CCA/200AH
<u>7L-7872</u>		Battery GP	Factory	—	24V BATTERY
9E-3867		Unknown Part	Factory	—	UNKNOWN PART
9E-4709		Unknown Part	Factory	—	UNKNOWN PART
9E-4710		Unknown Part	Factory	—	UNKNOWN PART
9E-4712		Unknown Part	Factory	—	UNKNOWN PART
9E-4822		Unknown Part	Factory	—	UNKNOWN PART
PA5370		Unknown Part	Factory	—	UNKNOWN PART
PA5371		Unknown Part	Factory	—	UNKNOWN PART
PL1697		Primary Fuel Filter	Factory	—	PRIMARY FUEL FILTER
PL4838		RH Mtg Of Control Panel	Factory	—	RH MTG OF CONTROL PANEL
PP2204		Unknown Part	Factory	—	UNKNOWN PART
1404	5NJ00946	Generator - -	Factory	—	GENERATOR

### Engine - Entire Group (2WJ02440)

Part Number	Change Level	Part Name	Install Ind.	Install Date
<u>↳4P-4969</u>	01	Box GP-Extension Terminal 	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
<a href="#">↪105-7185</a>	00	Harness AS-Panel (I)	—	—
<a href="#">↪106-9697</a>	00	Neutral Bus Bar AS (I)	—	—
<a href="#">↪108-1055</a>	00	Fastener GP-Extension Box (I)	—	—
<a href="#">↪108-1057</a>	01	Cable GP-Generator Ground (I)	—	—
<a href="#">105-7185</a>	00	Harness AS-Panel (I)	—	—
<a href="#">7E-0161</a>	14	Engine AR (I)	—	—
<a href="#">3N-6668</a>	05	Lines GP-Flexible Fuel (I)	—	—
<a href="#">4N-1061</a>	14	Starting Motor GP- Electric (I)	—	—
<a href="#">4P-7610</a>	02	Sensor GP-Speed (I)	—	—
<a href="#">6I-2026</a>	04	Connection GP-Electrical (I)	—	—
<a href="#">7E-9053</a>	01	Guard GP-Belt (I)	—	—
<a href="#">9Y-0450</a>	01	Generator AR (I)	—	—
<a href="#">9Y-6397</a>	05	Rail GP-Engine Support (I)	—	—
<a href="#">102-9942</a>	00	Mounting GP-Contactor (I)	—	—
<a href="#">103-1966</a>	05	Wiring GP-Engine	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
<u>103-6101</u>	04	Control GP-Engine Monitoring I	—	—
<u>104-4704</u>	03	Mounting GP-Control Panel I	—	—
<u>108-1467</u>	01	Coupling GP-Generator I	—	—
<u>6N-8878</u>	02	Gauge GP-Fuel Pressure I	—	—
<u>7E-4254</u>	00	Air Cleaner GP I	—	—
<u>121-4716</u>	01	Module GP-Alarm I	—	—
<u>121-4712</u>	01	Panel GP-Electronic I	—	—
<u>134-1157</u>	00	Relay GP I	—	—
<u>7C-5296</u>	01	Panel GP-Instrument I	—	—
<u>6N-4371</u>	02	Fan GP-Blower I	—	—
<u>6N-4874</u>	03	Lines GP-Water I	—	—
<u>7E-4257</u>	02	Radiator GP I	—	—
<u>7N-8847</u>	01	Drive GP-Fan I	—	—
<u>7E-4259</u>	00	Lines GP-Water I	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
<u>111-3794</u>	00	Sensor GP-Coolant Level (I)	—	—
<u>7L-7872</u>	08	Battery GP (I)	—	—
<u>7E-4261</u>	00	Fumes Disposal GP (I)	—	—
<u>6N-3212</u>	04	Mounting GP-Primary Fuel Fltr (I)	—	—
<u>8H-7204</u>	09	Filter GP-Fuel (I)	—	—
2L-3331		Connector-Pipe (S)	—	—
2V-7397		Cable AS (S)	—	—
3N-6667		Hose AS (S)	—	—
7C-1571		Filter Element AS-Air (S)	—	—
<u>7C-5296</u>		Panel GP-Instrument (S)	—	—
8L-8413		Strap-Cable (S)	—	—
8T-4988		Clamp-Hose (S)	—	—
9G-0003		Cover AS-Terminal (S)	—	—
9G-0004		Cover AS-Terminal (S)	—	—
<u>9X-9730</u>		Battery GP (S)	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
9Y-6102		Elbow <input type="checkbox"/>	—	—
9Y-6180		Tube <input type="checkbox"/>	—	—
003-2143		Elbow <input type="checkbox"/>	—	—