

**G3412 Gas Engine**

Machine Serial Number - 7DB01214

Machine Build Date - 08/24/1996

**G3412 Gas Engine**

Engine Serial Number - 7DB01214

Engine Build Date - 08/24/1996

**Product - Entire Group (7DB01214)**

Part Number	Serial Number	Part Name	Install Ind.	Install Date	Description
<a href="#">105-9777</a>		Engine AR	Factory	—	PRODUCT AR
<a href="#">108-1870</a>		Regulator GP-Voltage	Factory	—	UNKNOWN PART
<a href="#">2N-2342</a>		Valve AS-Solenoid	Factory	—	GAS VALVE - ETR 24V
<a href="#">2S-7227</a>		Starting Motor GP-Electric	Factory	—	ELECTRIC STARTING MOTOR 24V
<a href="#">2W-7848</a>		Fitting GP-Exhaust	Factory	—	CONEXAO FLEXIVEL
<a href="#">3N-7056</a>		Support GP-Battery	Factory	—	2 BATTERY RACK/FLOOR
<a href="#">3N-7056</a>		Support GP-Battery	Factory	—	SUPPORT AS
<a href="#">6N-4371</a>		Fan GP-Blower	Factory	—	BLOWER FAN 54 IN SL
7C-3874		Battery Charger	Factory	—	BATTERY CHARGER 10-AMP
<a href="#">7L-7872</a>		Battery GP	Factory	—	24V BAT SET-WET/1400CCA/200AH
<a href="#">7L-7872</a>		Battery GP	Factory	—	24V BATTERY
<a href="#">7N-8849</a>		Drive GP-Fan	Factory	—	FAN DRIVE 0.571 RATIO
<a href="#">7W-0825</a>		Cable GP-Battery	Factory	—	BATTERY CABLES
<a href="#">7W-0825</a>		Cable GP-Battery	Factory	—	BATTERY CABLES
PA4609		Unknown Part	Factory	—	UNKNOWN PART
PA4690		Unknown Part	Factory	—	UNKNOWN PART
PA4782		Auto S. S. Shutoff Op/wt	Factory	—	AUTO S. S. SHUTOFF OP/WT
PA5230		Unknown Part	Factory	—	UNKNOWN PART
PL4838		RH Mtg Of Control Panel	Factory	—	RH MTG OF CONTROL PANEL

Part Number	Serial Number	Part Name	Install Ind.	Install Date	Description
PP2957		Unknown Part	Factory	—	UNKNOWN PART

### Engine - Entire Group (7DB01214)

Part Number	Change Level	Part Name	Install Ind.	Install Date
<a href="#">105-9777</a>	08	Engine AR <input type="checkbox"/>	—	—
<a href="#">2W-1456</a>	07	Lines GP-Water <input type="checkbox"/>	—	—
<a href="#">2W-2949</a>	06	Control GP-Carburetor <input type="checkbox"/>	—	—
<a href="#">2W-4237</a>	03	Lines GP-Oil Supply <input type="checkbox"/>	—	—
<a href="#">2W-4685</a>	07	Lines GP-Turbocharger Oil <input type="checkbox"/>	—	—
<a href="#">4N-2328</a>	07	Meter GP-Service <input type="checkbox"/>	—	—
<a href="#">4P-3030</a>	04	Aftercooler GP-Water <input type="checkbox"/>	—	—
4P-3449	02	Lines GP-Air <input type="checkbox"/>	—	—
<a href="#">4P-6023</a>	05	Bypass GP-Exhaust <input type="checkbox"/>	—	—
<a href="#">4P-6715</a>	02	Mounting GP-Air Cleaner <input type="checkbox"/>	—	—
<a href="#">4P-6717</a>	00	Air Cleaner GP <input type="checkbox"/>	—	—
<a href="#">4P-6720</a>	00	Carburetor GP <input type="checkbox"/>	—	—
<a href="#">4P-6721</a>	04	Regulator GP-Gas Pressure <input type="checkbox"/>	—	—
<a href="#">6I-2160</a>	02	Actuator AS-Governor <input type="checkbox"/>	—	—
<a href="#">7W-9701</a>	07	Ignition GP-Gas Engine <input type="checkbox"/>	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
<a href="#">9Y-1268</a>	02	Pump GP-Auxiliary Water (I)	—	—
<a href="#">110-7837</a>	02	Control GP-Governor (I)	—	—
<a href="#">119-6230</a>	02	Manifold GP-Exhaust (I)	—	—
<a href="#">111-6836</a>	03	Lines GP-Water (I)	—	—
<a href="#">115-5866</a>	00	Turbocharger GP (I)	—	—
<a href="#">5N-2975</a>	05	Installation AR-Generator (I)	—	—
<a href="#">7E-1109</a>	01	Rail GP-Engine & Gen Support (I)	—	—
<a href="#">9Y-3877</a>	00	Generator AR (I)	—	—
<a href="#">101-9852</a>	02	Wiring GP-Engine (I)	—	—
<a href="#">102-9282</a>	01	Shutoff GP-Electrical (I)	—	—
<a href="#">6N-4371</a>	01	Fan GP-Blower (I)	—	—
<a href="#">7N-8849</a>	01	Drive GP-Fan (I)	—	—
<a href="#">2W-7848</a>	00	Fitting GP-Exhaust (I)	—	—
<a href="#">108-1870</a>	03	Regulator GP-Voltage (I)	—	—
<a href="#">6I-2760</a>	00	Wiring GP-Engine (I)	—	—
<a href="#">7W-0784</a>	02	Sender GP (I)	—	—
<a href="#">7W-0919</a>	03	Mounting GP-Control Panel (I)	—	—

Part Number	Change Level	Part Name	Install Ind.	Install Date
<a href="#">4P-9680</a>	01	Connection GP-Electrical (I)	—	—
<a href="#">2N-2342</a>	05	Valve AS-Solenoid (I)	—	—
<a href="#">2S-7227</a>	17	Starting Motor GP-Electric (I)	—	—
<a href="#">4P-7353</a>	00	Mounting GP-Jacket Wtr Heater (I)	—	—
<a href="#">7E-6248</a>	05	Heater GP-Jacket Water (I)	—	—
<a href="#">6I-2656</a>	00	Switch GP-Temperature (I)	—	—
<a href="#">7L-7872</a>	08	Battery GP (I)	—	—
<a href="#">7W-0825</a>	01	Cable GP-Battery (I)	—	—
<a href="#">3N-7056</a>	00	Support GP-Battery (I)	—	—
<a href="#">4W-8216</a>	00	Neutral Bus Bar AS (I)	—	—
<a href="#">7W-1021</a>	08	Mounting GP-Circuit Breaker (I)	—	—
<a href="#">7W-1091</a>	02	Cover-Extension Box (I)	—	—
<a href="#">104-4391</a>	00	Circuit Breaker GP (I)	—	—
<a href="#">105-7185</a>	00	Harness AS-Panel (I)	—	—
<a href="#">106-1771</a>	00	Fastener GP-Extension Box (I)	—	—
<a href="#">107-3058</a>	00	Box GP-Extension Terminal (I)	—	—